

# GOODWE



## User Manual

### Grid-Tied PV Inverter

HT Series  
(73-136kW)

V1.7-2025-07-10

**Copyright ©GoodWe Technologies Co., Ltd., 2025. All rights reserved**

No part of this manual can be reproduced or transmitted to the public platform in any form or by any means without the prior written authorization of GoodWe Technologies Co., Ltd.

**Trademarks**

**GOODWE** and other GoodWe trademarks are trademarks of GoodWe Company. All other trademarks or registered trademarks mentioned in this manual are owned by GoodWe Technologies Co., Ltd.

**Notice**

The information in this user manual is subject to change due to product updates or other reasons. This manual cannot replace the product labels or the safety precautions unless otherwise specified. All descriptions in the manual are for guidance only.

## CONTENT

|          |                                    |           |
|----------|------------------------------------|-----------|
| <b>1</b> | <b>About This Manual .....</b>     | <b>1</b>  |
| 1.1      | Applicable Model .....             | 1         |
| 1.2      | Target Audience .....              | 1         |
| 1.3      | Symbol Definition .....            | 1         |
| <b>2</b> | <b>Safety Precaution .....</b>     | <b>2</b>  |
| 2.1      | General Safety .....               | 2         |
| 2.2      | DC Side .....                      | 2         |
| 2.3      | AC Side .....                      | 3         |
| 2.4      | Inverter Installation .....        | 3         |
| 2.5      | Personal Requirements .....        | 4         |
| <b>3</b> | <b>Product Introduction .....</b>  | <b>4</b>  |
| 3.1      | Application Scenarios .....        | 4         |
| 3.2      | Circuit Diagram .....              | 4         |
| 3.3      | Supported Grid Types .....         | 6         |
| 3.4      | Appearance .....                   | 7         |
| 3.4.1    | Parts .....                        | 7         |
| 3.4.2    | Indicators .....                   | 9         |
| 3.4.3    | Nameplate .....                    | 10        |
| 3.5      | Functionalities .....              | 10        |
| <b>4</b> | <b>Check and Storage .....</b>     | <b>11</b> |
| 4.1      | Check Before Receiving .....       | 11        |
| 4.2      | Deliverables .....                 | 11        |
| 4.3      | Storage .....                      | 12        |
| <b>5</b> | <b>Installation .....</b>          | <b>13</b> |
| 5.1      | Installation Requirements .....    | 13        |
| 5.2      | Inverter Installation .....        | 16        |
| 5.2.1    | Moving the Inverter .....          | 16        |
| 5.2.2    | Installing the Inverter .....      | 16        |
| <b>6</b> | <b>Electrical Connection .....</b> | <b>18</b> |
| 6.1      | Safety Precautions .....           | 18        |
| 6.2      | Connecting the PE Cable .....      | 20        |

|                                                                          |           |
|--------------------------------------------------------------------------|-----------|
| 6.3 Connecting the PV Input Cable.....                                   | 21        |
| 6.4 Connecting the AC Output Cable.....                                  | 24        |
| 6.5 Communication.....                                                   | 26        |
| 6.5.1 Connecting the Communication Cable .....                           | 26        |
| 6.5.2 Connecting the Remote Shutdown Communication Cable (Optional)..... | 30        |
| 6.5.3 Connecting DRED Communication Cable (optional).....                | 32        |
| 6.5.4 Installing the Communication Module (optional) .....               | 33        |
| 6.5.5 Installing PV Protection Cover (Optional) .....                    | 34        |
| <b>7 Equipment Commissioning .....</b>                                   | <b>35</b> |
| 7.1 Check Items before Switching Power ON.....                           | 35        |
| 7.2 Power On .....                                                       | 35        |
| <b>8 System Commissioning.....</b>                                       | <b>36</b> |
| 8.1 Indicators and Button .....                                          | 36        |
| 8.2 Setting Inverter Parameters via LCD.....                             | 37        |
| 8.3 Setting Inverter Parameters via App.....                             | 40        |
| 8.4 Monitoring via SEMS Portal.....                                      | 40        |
| <b>9 Maintenance .....</b>                                               | <b>41</b> |
| 9.1 Power Off the Inverter .....                                         | 41        |
| 9.2 Removing the Inverter .....                                          | 41        |
| 9.3 Disposing of the Inverter.....                                       | 41        |
| 9.4 Troubleshooting.....                                                 | 42        |
| 9.5 Routine Maintenance .....                                            | 48        |
| <b>10 Technical Parameters.....</b>                                      | <b>49</b> |
| <b>11 Term Explanation.....</b>                                          | <b>55</b> |



# 1 About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting, and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit [www.en.goodwe.com](http://www.en.goodwe.com).

## 1.1 Applicable Model

This manual applies to the listed inverters below (HT for short):

| Model      | Nominal Output Power | Nominal Output Voltage                    |
|------------|----------------------|-------------------------------------------|
| GW73KLV-HT | 73kW                 | 220V, 3L/N/PE or 3L/PE                    |
| GW75K-HT   | 75kW                 | 380V/400V, 3L/N/PE or 3L/PE* <sup>1</sup> |
| GW80K-HT   | 80kW                 |                                           |
| GW100K-HT  | 100kW* <sup>2</sup>  | 400V, 3L/N/PE or 3L/PE* <sup>3</sup>      |
| GW110K-HT  | 110kW                |                                           |
| GW120K-HT  | 120kW                |                                           |
| GW136K-HTH | 136kW                | 500V, 3L/PE                               |

\*1: For Brazil Nominal Output Voltage (V): 380V, 3L/N/PE or 3L/PE.

\*2: For Australia is 99.99kW/kVA.

\*3: For Brazil Nominal Output Voltage (V): 380V, 3L/N/PE or 3L/PE.

## 1.2 Target Audience

This manual applies to trained and knowledgeable technical professionals. The technical personnel has to be familiar with the product, local standards, and electric systems.

## 1.3 Symbol Definition

Different levels of warning messages in this manual are defined as follows:

|                                                                                                                |
|----------------------------------------------------------------------------------------------------------------|
|  <b>DANGER</b>              |
| Indicates a high-level hazard that, if not avoided, will result in death or serious injury.                    |
|  <b>WARNING</b>             |
| Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.                 |
|  <b>CAUTION</b>             |
| Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.                   |
| <b>NOTICE</b>                                                                                                  |
| Highlight and supplement the texts. Or some skills and methods to solve product-related problems to save time. |

## 2 Safety Precaution



### WARNING

The inverters are designed and tested strictly to comply with related safety rules. Read and follow all the safety instructions and cautions before any operations. Improper operation might cause personal injury or property damage as the inverters are electrical equipment.

### 2.1 General Safety

#### Notice

- The information in this document is subject to change due to product updates or other reasons. This manual cannot replace the product labels or the safety precaution unless otherwise specified. All descriptions here are for guidance only.
- Before installations, read through the user manual to learn about the product and the precautions.
- All installations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, cloths, and wrist strips when touching electron devices to protect the inverter from damage.
- Strictly follow the installation, operation, and configuration instructions in this manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, visit <https://en.goodwe.com/warranty.asp>.

### 2.2 DC Side



### DANGER

- Connect the DC cables using the delivered DC connectors and terminals. The manufacturer shall not be liable for the equipment damage if other connectors or terminals are used.
- Confirm the following information before connecting the PV string to the inverter. Otherwise, the inverter may be damaged permanently or even cause fire and cause personal and property losses. Above damage or injuries are not covered by the warranty.
  - Make sure that the positive pole of the PV string connects to the PV+ of the inverter. And the negative pole of the PV string connects to the PV- of the inverter.
  - For the models of GW75K-HT, GW80K-HT, GW100K-HT, GW110K-HT, GW120K-HT, GW136K-HTH, the open circuit voltage of the PV string connected to each MPPT shall not exceed 1100V. When the input voltage is between 1000V and 1100V, the inverter enters the waiting mode. When the voltage returns to 180V-1000V, the inverter will resume normal operation.
  - For the models of GW73KLV-HT, the open circuit voltage of the PV string connected to each MPPT shall not exceed 800V.

**⚠ WARNING**

- Ensure that the PV module frames and the PV mounting system are securely grounded.
- Ensure that the DC cables are connected tightly and securely.
- The PV modules used with the inverter must have an IEC61730 class A rating.
- Make sure that the PV strings connected to the same MPPT should contain the same number of identical PV modules.
- To maximize the power generation of the inverter, please ensure that the  $V_{mp}$  of the PV modules connected in series is within the MPPT Voltage Range at Nominal Power of the inverter, as shown in the **Technical Parameters**.
- Make sure that the voltage difference between two MPPTs shall be less than 150 V.
- Make sure that the input current of each MPPT does not exceed the Max. Input Current per MPPT, as shown in the **Technical Parameters**.
- When there are multiple PV string inputs, please connect them to as much inverter MPPTs as possible.

## 2.3 AC Side

**⚠ WARNING**

- The voltage and frequency at the connecting point should meet the on-grid requirements.
- An additional protective device like the circuit breaker or fuse is recommended on the AC side. Specification of the protective device should be at least 1.25 times the Max. output current.
- You are recommended to use copper cables as AC output cables. If you prefer aluminum cables, remember to use copper to aluminum adapter terminals.

## 2.4 Inverter Installation

**⚠ DANGER**

- Terminals at the bottom of the inverter cannot bear much load. Otherwise, the terminals will be damaged.
- All labels and warning marks must be clear and distinct after the installation. Do not block, alter, or damage any label.
- Warning labels on the inverter are as follows.

|                                                                                    |                                                                                                   |                                                                                     |                                                                                                                                                            |
|------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | HIGH VOLTAGE HAZARD. Disconnect all incoming power and turn off the product before working on it. |  | Delayed discharge. Wait 5 minutes after power off until the components are completely discharged.                                                          |
|  | Read through the guide before working on this device.                                             |  | Potential risks exist. Wear proper PPE before any operations.                                                                                              |
|  | High-temperature hazard. Do not touch the product under operation to avoid being burnt.           |  | Grounding point. Indicates the position for connecting the PE cable.                                                                                       |
|  | CE marking                                                                                        |  | Do not dispose of the inverter as household waste. Discard the product in compliance with local laws and regulations, or send it back to the manufacturer. |

## 2.5 Personal Requirements


### NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

## 3 Product Introduction

### 3.1 Application Scenarios

The HT inverter is a three-phase PV string grid-tied inverter. The inverter converts the DC power generated by the PV module into AC power and feeds it into the utility grid. The intended use of the inverter is as follows:




### NOTICE


This series of products is suitable for commercial/industrial product use scenarios.

### 3.2 Circuit Diagram


The circuit diagram of GW75K-HT/GW80K-HT/GW100K-HT is as follows.



The circuit diagram of GW73KLV-HT/GW110K-HT/GW120K-HT is as follows.



The circuit diagram of GW136K-HTH is as follows.




### 3.3 Supported Grid Types


**NOTICE**

- For the TT grid structure, the effective value of the voltage between the neutral wire and the ground wire must be less than 20V.

The grid structures supported by GW73KLV-HT, GW75K-HT, GW80K-HT, GW100K-HT, GW110K-HT, GW120K-HT are TN-S, TN-C, TN-C-S, TT, IT, as shown in the figure below:




The grid structures supported by GW136K-HTH is IT, as shown in the diagram below:



## 3.4 Appearance

### 3.4.1 Parts



| No.               | Parts                                                      | Description                                                                                              |
|-------------------|------------------------------------------------------------|----------------------------------------------------------------------------------------------------------|
| 1                 | DC Switch 1-3                                              | Start or stop 1-3 DC input.                                                                              |
| 2                 | PV Input Terminal 1-3<br>(Controlled by DC Switch 1-3)     | Used to connect the PV module DC input cables.                                                           |
| 3                 | PV Input Terminal 7-9<br>(Controlled by DC Switch 7-9)     | Used to connect the PV module DC input cables.                                                           |
| 4                 | DC Switch 7-9                                              | Start or stop 7-9 DC input.                                                                              |
| 5                 | Communication Port                                         | Used to connect communication modules like Bluetooth, WiFi, GPRS, 4G, etc.                               |
| 6                 | RS485 Communication Port (COM2)                            | Used to connect RS485 communication cable, supporting connecting to other inverters or smart DataLogger. |
| 7                 | Remote Shutdown or DRED communication Port (COM3)          | Used to connect the Remote Shutdown or DRED communication cable.                                         |
| 8                 | AC Cable Outlet Hole                                       | -                                                                                                        |
| 9                 | DC Switch 4-6                                              | Start or stop 4-6 DC input.                                                                              |
| 10                | PV Input Terminal 4-6<br>(Controlled by DC Switch 4-6)     | Used to connect the PV module DC input cables.                                                           |
| 11 <sup>[a]</sup> | PV Input Terminal 10-12<br>(Controlled by DC Switch 10-12) | Used to connect the PV module DC input cables.                                                           |
| 12                | DC Switch 10-12                                            | Start or stop 10-12 DC input.                                                                            |
| 13                | Ventilation valve                                          | -                                                                                                        |
| 14                | RS485 communication Port (COM4) (optional)                 | Optional. Used to connect RS485 communication cable, supporting connecting the smart meter.              |
| 15                | Indicator                                                  | Indicates working state of the inverter.                                                                 |
| 16                | LCD (optional)                                             | Optional. Used to check the parameters of the inverter.                                                  |
| 17                | Button(optional)                                           | Optional. Used to control contents displayed on the screen.                                              |
| 18                | Fan                                                        | Used to cool the inverter.                                                                               |
| 19                | Grounding Point                                            | Used to connect the PE cable.                                                                            |

[a]. The number of PV terminals varies depending on the different inverters. The actual accessories may differ.



### 3.4.2 Indicators

| Indicator                                                                         | Status                                                                            | Description                                                  |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|--------------------------------------------------------------|
|  |  | ON = EQUIPMENT POWER ON                                      |
|                                                                                   |  | OFF = EQUIPMENT POWER OFF                                    |
|  |  | ON = THE INVERTER IS FEEDING POWER                           |
|                                                                                   |  | OFF = THE INVERTER IS NOT FEEDING POWER                      |
|                                                                                   |  | SINGLE SLOW FLASH = SELF CHECK BEFORE CONNECTING TO THE GRID |
|                                                                                   |  | SINGLE FLASH = CONNECTING TO THE GRID                        |
|  |  | ON = WIRELESS IS CONNECTED/ACTIVE                            |
|                                                                                   |  | BLINK 1 = WIRELESS SYSTEM IS RESETTNG                        |
|                                                                                   |  | BLINK 2 = WIRELESS ROUTER NOT CONNECTED                      |
|                                                                                   |  | BLINK 4 = WIRELESS SERVER PROBLEM                            |
|                                                                                   |  | BLINK = RS485 IS CONNECTED                                   |
|                                                                                   |  | OFF = WIRELESS IS NOT ACTIVE                                 |
|  |  | ON = A FAULT HAS OCCURRED                                    |
|                                                                                   |  | OFF = NO FAULT                                               |



## 4 Check and Storage

### 4.1 Check Before Receiving


Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and others signs of equipment damage. Do not unpack the package and contact the supplier as soon as possible if any damage is found.
2. Check the inverter model. If the inverter model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverables for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.

### 4.2 Deliverables

#### NOTICE

- The number of PV connectors and the PV terminals in the inverter is the same.
- The type and number of the communication connector are decided by the selected communication method.
- Communication module types: WiFi, 4G etc. The actual module delivered depends on the communication method of the selected inverter.
- The number of expansion bolts, screws, pin terminals are various depending on different inverters. The actual accessories may differ.
- The Unlock tool: optional.
- The RS485-USB cable will only be delivered in Brazil.
- Handles: Optional.



### 4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:







1. Do not unpack the outer package or throw the desiccant away.
2. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
3. Follow the instructions on the packing box when stacking the inverters. Stack with caution to prevent them from falling over.
4. If the inverter has been long term stored, it should be checked by professionals before being put into use.
5. If the inverter has been stored for more than two years or has not been in operation for more than six months after installation, it is recommended to be inspected and tested by professionals before being put into use.
6. To ensure good electrical performance of the internal electronic components of the inverter, it is recommended to power it on every 6 months during storage. If it has not been powered on for more than 6 months, it is recommended to be inspected and tested by professionals before being put into use.


## 5 Installation

### 5.1 Installation Requirements

#### Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Install the equipment on a surface that is solid enough to bear the inverter weight.
3. Install the equipment in a well-ventilated place to ensure good dissipation. Also, the installation space should be large enough for operations.
4. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
5. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
6. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
7. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
8. Install the inverters far away from noise-sensitive areas, such as the residential area, school, hospital etc., in order to avoid the noises bothering people nearby.
9. Install the inverter away from high magnetic field to avoid electromagnetic interference. If there is any radio or wireless communication equipment below 30MHz near the inverter, you have to:
  - Install the inverter at least 30m far away from the wireless equipment.
  - Add a low pass EMI filter or a multi winding ferrite core to the DC input cable or AC output cable of the inverter.






### Mounting Support Requirements

1. The mounting support shall be nonflammable and fireproof.
2. Make sure that the support surface is solid enough to bear the product weight load.







### Installation Angle Requirements

- Install the inverter vertically or at a maximum back tilt of 25 degrees.
- Do not install the inverter upside down, forward tilt, back forward tilt, or horizontally.



## Installation Tool Requirements

The following tools are recommended when installing the equipment. Use other auxiliary tools on site if necessary.

|                                                                                   |                                                                                   |                                                                                   |                                                                                   |                                                                                   |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
|  |  |  |  |  |
| Goggles                                                                           | Safety shoes                                                                      | Safety gloves                                                                     | Dust mask                                                                         | RJ45 crimping tool                                                                |
|  |  |  |  |  |
| Diagonal pliers                                                                   | Wire stripper                                                                     | Hammer drill                                                                      | Heat gun                                                                          | DC terminal crimping tool                                                         |
|  |  |  |  |  |
| Marker                                                                            | Level                                                                             | Heat shrink tube                                                                  | Rubber hammer                                                                     | DC wiring wrench                                                                  |
|  |  |  |  |                                                                                   |
| Multimeter                                                                        | Cable tie                                                                         | Torque wrench                                                                     | Vacuum cleaner                                                                    |                                                                                   |

## 5.2 Inverter Installation

### 5.2.1 Moving the Inverter



#### CAUTION

Move the inverter to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.

1. Consider the weight of the equipment before moving it. Assign enough personnel to move the equipment to avoid personal injury.
2. Wear safety gloves to avoid personal injury.
3. Keep balance when moving the equipment.

### 5.2.2 Installing the Inverter

#### NOTICE

- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- If you need to use the handles or hoisting rings, please contact after-sale service for purchase.

**Step 1** Put the mounting plate on the wall horizontally and mark positions for drilling holes. (Contact the local sales center to purchase the bracket)


**Step 2** Drill holes to a depth of 65mm using the hammer drill. The diameter of the drill bit should be 13mm.

**Step 3** Fix the mounting plate on the wall or the bracket.

**Step 4** Install the handles or the hoisting rings. Grab the handles to lift the inverter or hoist the inverter to place it on the mounting plate.

**Step 5** Tighten the nuts to secure the mounting plate and the inverter.





## 6 Electrical Connection

### 6.1 Safety Precautions

 **DANGER**

- Disconnect the DC switch and the AC output switch of the inverter to power off the equipment before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Perform electrical connections in compliance with local laws and regulations. Including operations, cables, and component specifications.
- If the tension is too large, the cable may be poorly connected. Reserve a certain length of the cable before connecting it to the inverter cable port.

**NOTICE**

- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications should meet local laws and regulations.

| No. | Cable                         | Type                                | Cable Specification                                                                                                                                                                                                                                                                                                                                                                                    |
|-----|-------------------------------|-------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | PE cable                      | Outdoors cable                      | Conductor cross sectional area $S_{PE} \geq S/2$                                                                                                                                                                                                                                                                                                                                                       |
| 2   | DC input cable                | PV cable that meets 1100V standard. | <ul style="list-style-type: none"><li>• Conductor cross sectional area: 4~6mm<sup>2</sup></li><li>• Cable outer diameter: 5.5mm~8mm</li></ul>                                                                                                                                                                                                                                                          |
| 3   | AC output cable (multi-core)  | Multi-core outdoor cable            | <ul style="list-style-type: none"><li>• Cable outer diameter: 22mm~67mm</li><li>• Copper core cable conductor cross sectional area: <math>70 \leq S \leq 240\text{mm}^2</math></li><li>• Aluminum alloy cable or copper-clad aluminum cable conductor cross sectional area: <math>95 \leq S \leq 240\text{mm}^2</math></li><li>• Conductor cross sectional area <math>S_{PE} \geq S/2</math></li></ul> |
| 4   | AC output cable (single core) | Single-core outdoor cable           | <ul style="list-style-type: none"><li>• Cable outer diameter: 11mm~35mm</li><li>• Copper core cable conductor cross sectional area: <math>70 \leq S \leq 240\text{mm}^2</math></li><li>• Aluminum alloy cable or copper-clad aluminum cable conductor cross sectional area: <math>95 \leq S \leq 240\text{mm}^2</math></li><li>• Conductor cross sectional area <math>S_{PE} \geq S/2</math></li></ul> |

|   |                           |                                                                          |                     |
|---|---------------------------|--------------------------------------------------------------------------|---------------------|
| 5 | RS485 communication cable | Outdoor shielded twisted pair. The cable should meet local requirements. | Cable Length: 1000m |
| 6 | Remote Shutdown Cable     | Outdoor shielded twisted pair. The cable should meet local requirements. | N/A                 |


Note: The values in this table are valid only if the external protective earthing conductor is made of the same metal as the phase conductors. Otherwise, the cross-sectional area of the external protective earthing conductor is to be determined in a manner which produces a conductance equivalent to that which results from the application of this table.

## 6.2 Connecting the PE Cable



### WARNING

- The PE cable connected to the enclosure of the inverter cannot replace the PE cable connected to the AC output port. Both of the two PE cables must be securely connected.
- Make sure that all the grounding points on the enclosures are equipotential connected when there are multiple inverters.
- To improve the corrosion resistance of the terminal, it is recommended to apply silica gel or paint on the ground terminal after installing the PE cable.
- The PE cable should be prepared by customers.
- M8 ground OT terminals should be prepared by customers.
- Other sizes of grounding cables that meet local standards and safety regulations can also be used for grounding connections. But GOODWE shall not be held liable for any damage caused.




## 6.3 Connecting the PV Input Cable

### DANGER

- Do not connect the same PV string to multiple inverters, as this may cause damage to the inverter.
- Confirm the following information before connecting the PV string to the inverter. Otherwise, the inverter may be damaged permanently or even cause fire and cause personal and property losses. Above damage or injuries are not covered by the warranty.
  - Make sure that the positive pole of the PV string connects to the PV+ of the inverter. And the negative pole of the PV string connects to the PV- of the inverter.
  - For the models of GW75K-HT, GW80K-HT, GW100K-HT, GW110K-HT, GW120K-HT, GW136K-HTH, the open circuit voltage of the PV string connected to each MPPT shall not exceed 1100V. When the input voltage is between 1000V and 1100V, the inverter enters the waiting mode. When the voltage returns to 180V-1000V, the inverter will resume normal operation.
  - For the models of GW73KLV-HT, the open circuit voltage of the PV string connected to each MPPT shall not exceed 800V.

### WARNING

- Connect the DC cables using the delivered PV connectors. The manufacturer shall not be liable for the damage if other connectors are used.
- The PV strings cannot be grounded. Ensure the minimum isolation resistance of the PV string to the ground meets the minimum isolation resistance requirements before connecting the PV string to the inverter.
- The DC input cable should be prepared by customers.



**NOTICE**

Seal the PV input terminals using waterproof covers when they are not to be used. Otherwise, the ingress protection rating will be influenced.

**Connecting the DC Input Cable**



**Step 1** Prepare DC cables.

**Step 2** Crimp the crimp contacts.


**Step 3** Disassemble the PV connectors.

**Step 4** Make the DC cable and detect the DC input voltage.

**Step 5** Plug the PV connectors into the PV terminals.

**Vaconn DC Connector****QC4.10 DC Connector**

## MC4 DC Connector



6.4 Connecting the AC Output Cable

 **WARNING**

Do not connect loads between the inverter and the AC switch directly connected to it.

Select and Install RCD depending on local laws and regulations. Type A RCDs (Residual Current Monitoring Device) can be connected to the outside of the inverter for protection when the DC component of the leakage current exceeds the limit value. The following RCDs are for reference:

| Inverter model | Recommended RCD specifications |
|----------------|--------------------------------|
| GW73KLV-HT     | 730mA or higher                |
| GW75K-HT       | 750mA or higher                |
| GW80K-HT       | 800mA or higher                |
| GW100K-HT      | 1000mA or higher               |
| GW110K-HT      | 1100mA or higher               |
| GW120K-HT      | 1200mA or higher               |
| GW136K-HTH     | 1360mA or higher               |

An AC circuit breaker should be installed on the AC side to make sure that the inverter can safety disconnect the grid when an exception happens. Select the appropriate AC circuit breaker in compliance with local laws and regulations. Recommended AC circuit breakers:

| Inverter model              | AC circuit breaker |
|-----------------------------|--------------------|
| GW75K-HT/GW80K-HT/GW100K-HT | 200A               |
| GW110K-HT                   | 250A               |
| GW73KLV-HT/GW120K-HT        | 250A               |
| GW136K-HTH                  | 225A               |

**NOTICE**

Install one AC circuit breaker for each inverter. Multiple inverters cannot share one AC circuit breaker.

 **WARNING**

- Pay attention to the silkscreens L1, L2, L3, N, PE on the AC terminal. Connect the AC cables to the corresponding terminals. The inverter may be damaged if the cables are connected inappropriately.
- Make sure that the whole cable cores are inserted into the AC terminal holes. No part of the cable core can be exposed.
- Make sure that the cables are connected securely. Otherwise, the terminal may be too hot to damage the inverter when the inverter is working.
- Three-phase four-wire or three-phase five-wire cables can be connected to the AC terminals. The actual wiring method may be different. The figure below takes the three-phase five-wire as an example.
- The waterproof rubber ring for the AC outlet hole is delivered with the inverter, which is located in the AC junction box of the inverter. Please select the rubber ring types according to the actual using cables' specification.
- Reserve certain length of PE cable. Make ensure that the PE cable is the last one to bear the stress when the AC output cable is under tension.
- M8 ground OT terminals and M12 AC OT terminals should be prepared by customers.



**Step 1** Make the AC output cable.


**Step 2** Dismantle the AC cover and take out the rubber ring.

**Step 3** Cut the rubber ring to right size.





**Step 4** Crimp the AC cable OT terminal


**Step 5** Connect the AC output cables and install the cover.

Multi-core cable:



Single-core cable





### NOTICE

- Make sure that the cables are connected correctly and firmly after connections. Clean all the debris in the maintenance compartment.
- Seal the AC output terminal to ensure the Ingress Protection Rating.

## 6.5 Communication



### NOTICE

- Make sure that the communication device is connected to the right COM port.
- Route the communication cable far away from any interference source or power cable to prevent the signal from being influenced.
- GW136K-HTH Inverter has generation/export limit control functionality but is not tested to AS/NZS 4777.2:2020.


### Power limit networking scenario

#### 6.5.1 Connecting the Communication Cable


| Communication Type | COM Port        | Port Definition                                                                                                    | Function Description                                                                         |
|--------------------|-----------------|--------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------|
| RS485              | COM2            | 1: RS485_A1<br>2: RS485_B1<br>3: RS485_A1<br>4: RS485_B1<br>5: shield layer grounding<br>6: shield layer grounding | Used to connect the RS485 port of other inverters , EzLogger Pro. Ezlogger3000C, or SEC1000. |
|                    | COM4 (optional) | 1: RS485_A2<br>2: RS485_B2<br>3: RS485_A2<br>4: RS485_B2<br>5: shield layer grounding<br>6: shield layer grounding | Used to connect the smart meter to perform the power limit function.                         |

**Power limit networking scenario (SEC1000)****Power limit networking scenario (GM3000C optional )**

After completing cable connections, set related parameters via LCD or SolarGo app to enable export power limit control or output power limit control.

**RS485 networking scenario**


Ezlink networking scenario




Connecting the RS485 Communication Cable

NOTICE


Connect the RS485 cable using a 6PIN communication terminal as follows.





### 6.5.2 Connecting the Remote Shutdown Communication Cable (Optional)

#### Remote Shutdown networking scenario







#### Connecting the Remote Shutdown Communication Cable

| Communication Type | COM Port | Port Definition                                                    | Function Description                                                                                                             |
|--------------------|----------|--------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Remote Shutdown    | COM3     | 1: DI+<br>2: DI-<br>3: Reserved<br>4: Reserved<br>5: DI+<br>6: DI- | The remote shutdown port is reserved to meet the safety regulations in Europe. Related devices have to be prepared by customers. |

#### NOTICE

Connect the Remote Shutdown cable using a 6PIN communication terminal as follows.






### NOTICE

The Remote Shutdown communication port is installed with a short circuit wire. Remove the short circuit wire and keep it properly when enabling the Remote Shutdown function. Install the short circuit wire in PIN2 and PIN5 of the COM3 port when disabling the Remote Shutdown function.


6.5.3 Connecting DRED Communication Cable (optional)

| COM Port | Communication Type | Port Definition                                                              | Function Description                                                                                                                           |
|----------|--------------------|------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| COM3     | DRED               | 1: COM/DRM0<br>2: DRM4/8<br>3: DRM3/7<br>4: DRM2/6<br>5: DRM1/5<br>6: REFGEN | DRED (Demand Response Enabling Device): The inverter provides a DRM signal control port to meet the Australian DRM certification requirements. |

DRED Circuit




Multiple Inverter DRED






## Connecting communication cable



### 6.5.4 Installing the Communication Module (optional)

Plug a communication module into the inverter to establish a connection between the inverter and the smartphone or web pages. The communication module can be a WiFi module, or 4G module. Set inverter parameters, check running information and fault information, and observe system status in time via the smartphone or web pages.



### NOTICE

Refer to the delivered communication module user manual to get more introduction to the module. For more detailed information, visit <https://en.goodwe.com/>.

## 6.5.5 Installing PV Protection Cover (Optional)


### NOTICE

- After connect the inverter, you can install a PV protective cover to protect the DC terminals (optionally).
- Please contact the distributor or after-sales service center to buy the outside fuse if the fuse is needed.
- If you have install an external fuse to the DC terminal of the inverter, you need to provide a PV protective cover of appropriate size by yourself.

**Step 1:** Put the protective cover horizontally on the wall or bracket, and use a marker to mark the drilling position.

**Step 2:** Drill holes to a depth of 65mm using the hammer drill. The diameter of the drill bit should be 13mm.

**Step 3:** Fix the protective cover to the wall or bracket with expansion screws or combination bolts.



## 7 Equipment Commissioning


### 7.1 Check Items before Switching Power ON

| No. | Check Item                                                                                                   |
|-----|--------------------------------------------------------------------------------------------------------------|
| 1   | The inverter is firmly installed in a clean place where is well-ventilated and easy to operate.              |
| 2   | The PE cable, DC input cable, AC output cable, and communication cable are connected correctly and securely. |
| 3   | Cable ties are routed properly and evenly, and no burrs.                                                     |
| 4   | Unused ports and terminals are sealed.                                                                       |
| 5   | The voltage and frequency at the connection point meet the on-grid requirements.                             |

### 7.2 Power On

**Step 1** Turn on the AC switch between the inverter and the utility grid.

**Step 2** Turn on the DC switch of the inverter.



The DC switch locking hole is for Australia only.

#### Power ON

Turn on **1** → **2**

#### Power OFF

Turn off **1** → **3**

# 8 System Commissioning

## 8.1 Indicators and Button

Model without LCD



Model with LCD



| Indicator | Status | Description                                                  |
|-----------|--------|--------------------------------------------------------------|
|           |        | ON = EQUIPMENT POWER ON                                      |
|           |        | OFF = EQUIPMENT POWER OFF                                    |
|           |        | ON = THE INVERTER IS FEEDING POWER                           |
|           |        | OFF = THE INVERTER IS NOT FEEDING POWER                      |
|           |        | SINGLE SLOW FLASH = SELF CHECK BEFORE CONNECTING TO THE GRID |
|           |        | SINGLE FLASH = CONNECTING TO THE GRID                        |
|           |        | ON = WIRELESS IS CONNECTED/ACTIVE                            |
|           |        | BLINK 1 = WIRELESS SYSTEM IS RESETING                        |
|           |        | BLINK 2 = WIRELESS ROUTER NOT CONNECTED                      |
|           |        | BLINK 4 = WIRELESS SERVER PROBLEM                            |
|           |        | BLINK = RS485 IS CONNECTED                                   |
|           |        | OFF = WIRELESS IS NOT ACTIVE                                 |
|           |        | ON = A FAULT HAS OCCURRED                                    |
|           |        | OFF = NO FAULT                                               |

## 8.2 Setting Inverter Parameters via LCD

### NOTICE


- The screen shots are for reference only. The actual display may differ.
- The name, range, and default value of the parameters is subject to change or adjust. The actual display prevails.
- the power parameters should be set by professionals to prevent the generating capacity from being influenced by wrong parameters.

### LCD Button Description

Stop pressing the button for a period in any page, the LCD will get dark and go back to the initial page, which means the parameter in that page has been saved successfully.

This part describes the menu structure, allowing you view inverter information and set parameters more conveniently.

## Second level menu





### 8.3 Setting Inverter Parameters via App

SolarGo is an application used to communicate with the inverter via Bluetooth module, WiFi module, Wi-Fi/LAN module, or 4G module. Commonly used functions:

1. Check the operating data, software version, alarms of the inverter, etc.
2. Set grid parameters and communication parameters of the inverter.
3. Maintain the equipment.

For more details, refer to the SolarGo APP User Manual. Scan the QR code or visit [https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW\\_SolarGo\\_User%20Manual-EN.pdf](https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SolarGo_User%20Manual-EN.pdf) to get the user manual.



SolarGo App



SolarGo App  
User Manual

### 8.4 Monitoring via SEMS Portal

SEMS Portal is an monitoring platform used to manage organizations/users, add plants, and monitor plant status.

For more details, refer to the SEMS Portal User Manual. Scan the QR code or visit [https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW\\_SEMS%20Portal-User%20Manual-EN.pdf](https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SEMS%20Portal-User%20Manual-EN.pdf) to get the user manual.



SEMS Portal



SEMS Portal  
User Manual



## 9 Maintenance

### 9.1 Power Off the Inverter

#### DANGER

- Power off the inverter before operations and maintenance. Otherwise, the inverter may be damaged or electric shocks may occur.
- Delayed discharge. Wait until the components are discharged after power off.

**Step 1** Issue a command to the inverter for halting the grid via SolarGo APP.

**Step 2** Turn off the AC switch between the inverter and the utility grid.

**Step 3** Turn off the DC switch of the inverter.

### 9.2 Removing the Inverter

#### WARNING

- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

**Step 1** Disconnect all the cables, including DC cables, AC cables, communication cables, the communication module, and PE cables.

**Step 2** Handle or hoist the inverter to take it down from the wall or the bracket.

**Step 3** Store the inverter properly. If the inverter needs to be used later, ensure that the storage conditions meet the requirements.

### 9.3 Disposing of the Inverter

If the inverter cannot work any more, dispose of it according to the local disposal requirements for electrical equipment waste. Do not dispose of it as household waste.

## 9.4 Troubleshooting

Perform troubleshooting according to the following methods. Contact the after-sales service if these methods do not work.

Collect the information below before contacting the after-sales service, so tha the problems can be solved quickly.

1. Inverter information like serial number, software version, installation date, fault time, fault frequency, etc.
2. Installation environment, including weather conditions, whether the PV modules are sheltered or shadowed, etc. It is recommended to provide some photos and videos to assist in analyzing the problem.
3. Utility grid situation.

| No. | Fault             | Cause                                                                                                                                                                       | Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|-----|-------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   | SPI Comm Fail     | <ol style="list-style-type: none"> <li>1. The chip is not powered on.</li> <li>2. The chip program version is wrong.</li> </ol>                                             | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| 2   | EEPROM Fail       | The internal memory Flash is abnormal.                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 3   | Fac Fail          | Utility grid exception. The actual grid frequency change rate does not meet the requirement of the local grid standard.                                                     | <ol style="list-style-type: none"> <li>1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>2. If the problem occurs frequently, check whether the grid frequency is within the permissible range.                             <ul style="list-style-type: none"> <li>• Contact the local power company if the grid frequency exceeds the permissible range.</li> <li>• Contact the dealer or the after-sales service if the grid frequency is within the permissible range.</li> </ul> </li> </ol> |
| 4   | DC-SPD            | The inverter is struck by lightning.                                                                                                                                        | <ol style="list-style-type: none"> <li>1. Improve the lightning protection facilities around the inverter.</li> <li>2. Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.</li> </ol>                                                                                                                                                                                                                                                                                                                                      |
| 5   | Night DCSPS Fault | <ol style="list-style-type: none"> <li>1. Temporary abnormality is caused by environmental factors.</li> <li>2. Internal components of the inverter are damaged.</li> </ol> | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |

| No. | Fault            | Cause                                                                                                                                                                                                                                    | Solutions                                                                                                                                                                    |
|-----|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 6   | Relay Fail       | <ol style="list-style-type: none"> <li>1. The relay is abnormal or short-circuited.</li> <li>2. The control circuit is abnormal.</li> <li>3. The AC cable connection is abnormal, like a virtual connection or short circuit.</li> </ol> | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p> |
| 7   | BUS-start Fail   | <ol style="list-style-type: none"> <li>1. The output power of the PV string is too low.</li> <li>2. The control circuit is abnormal.</li> </ol>                                                                                          | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p> |
| 8   | OVGRFault        | <ol style="list-style-type: none"> <li>1. The output voltage value of the PV string is lower than the minimum DC input voltage value of the inverter.</li> <li>2. The control circuit is abnormal.</li> </ol>                            | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p> |
| 9   | Pv Reverse Fault | The PV string is connected reversely.                                                                                                                                                                                                    | Check whether the PVstrings is connected reversely.                                                                                                                          |
| 10  | Night BUS Fault  | <ol style="list-style-type: none"> <li>1. Utility grid power fails.</li> <li>2. The AC cable is disconnected, or the AC breaker is off.</li> </ol>                                                                                       | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p> |
| 11  | CPLD Error       | <ol style="list-style-type: none"> <li>1. Temporary abnormality is caused by environmental factors.</li> <li>2. Internal components of the inverter are damaged.</li> </ol>                                                              | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p> |

| No. | Fault         | Cause                                                                                                                                                                                                         | Solutions                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|-----|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 12  | DCi High      | The machine detects that the DC component of the internal output current exceeds the normal range.                                                                                                            | Please contact your dealer or after-sale service.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
| 13  | ISO Fail      | <ol style="list-style-type: none"> <li>1. The PV system is short-circuited to the ground.</li> <li>2. The PV system is in a moist environment and the circuit is not well insulated to the ground.</li> </ol> | <ol style="list-style-type: none"> <li>1. Check whether the PV input cables are broken.</li> <li>2. Check whether the module frames and the metal bracket are securely grounded.</li> <li>3. Check whether the AC side is properly grounded</li> </ol> <p>Inverters sold in Australia and New Zealand will also alarm as following when Isolation Fail occurs.</p> <ol style="list-style-type: none"> <li>1. The buzzer in the inverter will sound for 1minute. If the problem persists, the buzzer willsound every 30 min.</li> <li>2. After adding the inverter to SEMS Portal, the alarm information will be emailed to the customers via SEMS Portal.</li> </ol> |
| 14  | Vac Failure   | The utility grid voltage is out of the allowed range.                                                                                                                                                         | <ol style="list-style-type: none"> <li>1. Make sure that the grid voltage is within the allowed range.</li> <li>2. Make sure that the phase sequence of the AC cables are connected correctly, and the neutral wire and PE cable are connected properly and firmly.</li> </ol>                                                                                                                                                                                                                                                                                                                                                                                       |
| 15  | ExFan Failure | <ol style="list-style-type: none"> <li>1. The fan power supply is abnormal.</li> <li>2. Mechanical exception.</li> <li>3. The fan is aging and damaged.</li> </ol>                                            | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 16  | GFCI Chk Fail | The sampling of the GFCI HCT is abnormal.                                                                                                                                                                     | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| 17  | AFCI Fault    | <ol style="list-style-type: none"> <li>1. The DC string terminal is not firmly connected.</li> <li>2. The DC cable is broken.</li> </ol>                                                                      | Please check whether the wirings of the PV modules are correct according to the requirements in the user manual.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |

| No. | Fault            | Cause                                                                                                                                                                                                                              | Solutions                                                                                                                                                                                                                                                                                                                                                                            |
|-----|------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 18  | Over Temperature | <ol style="list-style-type: none"> <li>1. The inverter is installed in a place with poor ventilation.</li> <li>2. The ambient temperature exceeds 60°C.</li> <li>3. A fault occurs in the internal fan of the inverter.</li> </ol> | <ol style="list-style-type: none"> <li>1. Check the ventilation and the ambient temperature at the installation point.</li> <li>2. If the ventilation is poor or the ambient temperature is too high, improve the ventilation and heat dissipation.</li> <li>3. Contact the dealer or after-sales service if both the ventilation and the ambient temperature are normal.</li> </ol> |
| 19  | InFan Fail       | <ol style="list-style-type: none"> <li>1. The fan power supply is abnormal.</li> <li>2. Mechanical exception.</li> <li>3. The fan is aging and damaged.</li> </ol>                                                                 | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                       |
| 20  | DC Bus High      | <ol style="list-style-type: none"> <li>1. The PV voltage is too high.</li> <li>2. The sampling of the inverter BUS voltage is abnormal.</li> </ol>                                                                                 | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                       |
| 21  | Gnd I Fail       | The input insulation impedance to the ground decreases when the inverter is operating.                                                                                                                                             | <ol style="list-style-type: none"> <li>1. Check whether the working environment of the inverter meets the requirements. For example, the fault may occur due to high humidity on rainy days</li> <li>2. Make sure that the components are properly grounded and the AC side is properly grounded.</li> </ol>                                                                         |
| 22  | Utility Loss     | <ol style="list-style-type: none"> <li>1. Utility grid power fails.</li> <li>2. The AC cable is disconnected, or the AC breaker is off.</li> </ol>                                                                                 | <ol style="list-style-type: none"> <li>1. The alarm is automatically cleared after the grid power supply is restored.</li> <li>2. Check whether the AC cable is connected and the AC breaker is on.</li> </ol>                                                                                                                                                                       |
| 23  | AC HCT Fail      | The sampling of the AC HCT is abnormal.                                                                                                                                                                                            | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                       |
| 24  | Relay Fail       | <ol style="list-style-type: none"> <li>1. The relay is abnormal or short-circuited.</li> <li>2. The control circuit is abnormal.</li> </ol>                                                                                        | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                                                                                                       |

| No. | Fault            | Cause                                                                                                               | Solutions                                                                                                                                                                                                                          |
|-----|------------------|---------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 25  | GFCI Chk Fail    | The sampling of the GFCI HCT is abnormal.                                                                           | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                     |
| 26  | SPD Failure      | The inverter is struck by lightning.                                                                                | 3. Improve the lightning protection facilities around the inverter. Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists. |
| 27  | DC Switch Fail   | The tripping times of the DC trip switch exceeds the limit.                                                         | Please contact your dealer or after-sale service.                                                                                                                                                                                  |
| 28  | Ref-V Chk Fail   | The reference circuit is faulty.                                                                                    | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                     |
| 29  | HCT Chk Fail     | The AC sensor is abnormal in sampling.                                                                              |                                                                                                                                                                                                                                    |
| 30  | PID Error        | 1. The system grounding is abnormal.<br>2. The PID module is abnormal.                                              | 1. Check whether the DC connecting and AC connecting cables are abnormal.<br>2. Check whether the PID module is abnormal.<br>3. Contact your dealer or after-sales service.                                                        |
| 31  | CPLD Error       | 1. Temporary abnormality is caused by environmental factors.<br>2. Internal components of the inverter are damaged. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                     |
| 32  | PV over Curr     | 1. The PV module configuration is not reasonable.<br>2. The hardware is damaged.                                    | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                     |
| 34  | PV soft OverCurr |                                                                                                                     |                                                                                                                                                                                                                                    |
| 35  | Model Error      | 1. Temporary abnormality is caused by environmental factors.<br>2. Internal components of the inverter are damaged. | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                     |

| No. | Fault            | Cause                                                                                                                                           | Solutions                                                                                                                                                                                                                                                                                          |
|-----|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 36  | Pv Short Failure | The hardware is abnormal.                                                                                                                       | Please contact your dealer or after-sale service.                                                                                                                                                                                                                                                  |
| 37  | BUS-start Fail   | <ol style="list-style-type: none"> <li>1. The output power of the PV string is too low.</li> <li>2. The control circuit is abnormal.</li> </ol> | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p>                                                                                                                       |
| 38  | PV Over Voltage  | Excess PV modules are connected in the series, and the open-circuit voltage is higher than the operating voltage.                               | <ol style="list-style-type: none"> <li>1. Check whether the PV string input voltage consistent with the value displayed on the LCD.</li> <li>2. Check whether the PV string voltage meets the maximum input voltage requirements.</li> </ol>                                                       |
| 39  | PV Voltage Low   | Sun light is weak or changing abnormally.                                                                                                       | <ol style="list-style-type: none"> <li>1. If the problem occurs occasionally, the reason might be abnormal sun light. The inverter will recover automatically without manual intervention.</li> <li>2. If the problem occurs frequently, contact the dealer or the after-sales service.</li> </ol> |
| 40  | PV HCT Fail      | 1. Temporary abnormality is caused by environmental factors.                                                                                    | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                     |
| 41  | PV over Curr     | 2. Internal components of the inverter are damaged.                                                                                             | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.                                                                                                                                     |
| 42  | Bus Unbalance    | <ol style="list-style-type: none"> <li>1. The sampling circuit of the relay is abnormal.</li> <li>2. Abnormal hardwares</li> </ol>              | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later.</p> <p>Contact the dealer or the after-sales service if the problem persists.</p>                                                                                                                       |

## 9.5 Routine Maintenance



Power off the inverter before operations and maintenance. Otherwise, the inverter may be damaged or electric shocks may occur.

| Maintaining Item      | Maintaining Method                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            | Maintaining Period |
|-----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|
| System Clean          | Check the heat sink, air intake, and air outlet for foreign matter or dust.                                                                                                                                                                                                                                                                                                                                                                                                                                                                   | Once 6-12 months   |
| Fan                   | Check the fan for proper working status, low noise, and intact appearance.                                                                                                                                                                                                                                                                                                                                                                                                                                                                    | Once a year        |
| DC Switch             | Turn the DC switch on and off ten consecutive times to make sure that it is working properly.                                                                                                                                                                                                                                                                                                                                                                                                                                                 | Once a year        |
| Electrical Connection | Check whether the cables are securely connected. Check whether the cables are broken, or whether there is any exposed copper core.                                                                                                                                                                                                                                                                                                                                                                                                            | Once 6-12 months   |
| Sealing               | Check whether all the terminals and ports are properly sealed. Reseal the cable hole if it is not sealed or too big.                                                                                                                                                                                                                                                                                                                                                                                                                          | Once a year        |
| THDi Test             | <p>For Australia requirements, in the THDi test, there should add Zref between inverter and mains.</p> <p>Zref:</p> <p>Zmax or Zref (phase current&gt;16A)</p> <p>Zref: L: <math>0.24\ \Omega + j0.15\ \Omega</math>; N: <math>0.16\ \Omega + j0.10\ \Omega</math> (phase current&gt;16A, &lt;21.7A)</p> <p>Zref: L: <math>0.15\ \Omega + j0.15\ \Omega</math>; N: <math>0.1\ \Omega + j0.1\ \Omega</math> (phase current&gt;21.7A, &lt;75A)</p> <p>Zref: <math>\geq 5\% U_n/I_{rated} + j5\% U_n/I_{rated}</math> (phase current&gt;75A)</p> | As needed          |



## 10 Technical Parameters

| Technical Data                                                   | GW100K-HT                           | GW110K-HT              | GW120K-HT              | GW136K-HTH             |
|------------------------------------------------------------------|-------------------------------------|------------------------|------------------------|------------------------|
| <b>Input</b>                                                     |                                     |                        |                        |                        |
| Max.Input Power (kW)                                             | 150                                 | 165                    | 180                    | 205                    |
| Max.Input Voltage (V) <sup>*3</sup>                              | 1100                                | 1100                   | 1100                   | 1100                   |
| MPPT Operating Voltage Range (V)                                 | 180~1000 <sup>*4</sup>              | 180~1000 <sup>*4</sup> | 180~1000 <sup>*4</sup> | 180~1000 <sup>*4</sup> |
| MPPT Voltage Range at Nominal Power (V)                          | 500~850                             | 500~850                | 500~850                | 500~850                |
| Start-up Voltage (V)                                             | 200                                 | 200                    | 200                    | 200                    |
| Nominal Input Voltage (V)                                        | 600                                 | 600                    | 600                    | 750                    |
| Max. Input Current per MPPT (A)                                  | 30                                  | 30                     | 30                     | 30                     |
| Max. Short Circuit Current per MPPT (A)                          | 45                                  | 45                     | 45                     | 45                     |
| Max. Backfeed Current to The Array (A)                           | 0                                   | 0                      | 0                      | 0                      |
| Number of MPPT Trackers                                          | 10                                  | 12                     | 12                     | 12                     |
| Number of Strings per MPPT                                       | 2                                   | 2                      | 2                      | 2                      |
| <b>Output</b>                                                    |                                     |                        |                        |                        |
| Nominal Output Power (kW)                                        | 100 <sup>*1</sup>                   | 110                    | 120                    | 136                    |
| Nominal Output Apparent Power (kVA)                              | 100 <sup>*1</sup>                   | 110                    | 120                    | 136                    |
| Max. AC Active Power (kW)                                        | 110 <sup>*1</sup>                   | 121                    | 132                    | 150                    |
| Max. AC Apparent Power (kVA)                                     | 110 <sup>*1</sup>                   | 121                    | 132                    | 150                    |
| Nominal Power at 40°C(kW) (Only for Brazil)                      | 100                                 | 110                    | 120                    | 136                    |
| Max Power at 40°C (Including AC Overload) (kW) (Only for Brazil) | 110                                 | 121@400V               | 132@400V               | 150                    |
| Nominal Output Voltage (V)                                       | 400, 3L/N/PE or 3L/PE <sup>*2</sup> |                        |                        | 500 , 3L/PE            |
| Output Voltage Range (V)                                         | 320~440                             |                        |                        | 425~550                |
| Nominal AC Grid Frequency (Hz)                                   | 50 / 60                             | 50 / 60                | 50 / 60                | 50 / 60                |
| AC Grid Frequency Range (Hz)                                     | 45~55/55~65                         |                        |                        |                        |
| Max. Output Current (A)                                          | 167.0                               | 175.5                  | 191.3                  | 173.2                  |
| Max. Output Fault Current (Peak and Duration) (A)                | 364@5μs                             | 364@5μs                | 364@5μs                | 364@5μs                |
| Inrush Current (Peak and Duration) (A)                           | 120@1μs                             | 120@1μs                | 120@1μs                | 120@1μs                |
| Nominal Output Current (A)                                       | 144.3                               | 158.8                  | 173.2                  | 157.0                  |

| Technical Data                            | GW100K-HT                                       | GW110K-HT | GW120K-HT | GW136K-HTH                          |
|-------------------------------------------|-------------------------------------------------|-----------|-----------|-------------------------------------|
| Power Factor                              | ~1 (Adjustable from 0.8 leading to 0.8 lagging) |           |           |                                     |
| Max. Total Harmonic Distortion            | <3%                                             | <3%       | <3%       | <3%                                 |
| Maximum Output Overcurrent Protection (A) | 340                                             | 340       | 340       | 340                                 |
| Efficiency                                |                                                 |           |           |                                     |
| Max. Efficiency                           | 98.6%                                           | 98.6%     | 98.6%     | 99.0%                               |
| European Efficiency                       | 98.3%                                           | 98.3%     | 98.3%     | 98.5%                               |
| Protection                                |                                                 |           |           |                                     |
| PV String Current Monitoring              | Integrated                                      |           |           |                                     |
| Internal Humidity Monitoring              | Integrated                                      |           |           |                                     |
| PV Insulation Resistance Detection        | Integrated                                      |           |           |                                     |
| Residual Current Monitoring               | Integrated                                      |           |           |                                     |
| PV Reverse Polarity Protection            | Integrated                                      |           |           |                                     |
| Anti-islanding Protection                 | Integrated                                      |           |           |                                     |
| AC Overcurrent Protection                 | Integrated                                      |           |           |                                     |
| AC Short Circuit Protection               | Integrated                                      |           |           |                                     |
| AC Overvoltage Protection                 | Integrated                                      |           |           |                                     |
| DC Switch                                 | Integrated                                      |           |           |                                     |
| DC Surge Protection                       | Type II                                         |           |           |                                     |
| AC Surge Protection                       | Type II                                         |           |           |                                     |
| AFCI                                      | Optional                                        |           |           |                                     |
| Remote Shutdown                           | Optional                                        |           |           |                                     |
| PID Recovery                              | Optional                                        |           |           |                                     |
| General Data                              |                                                 |           |           |                                     |
| Operating Temperature Range (°C)          | -30 ~ 60                                        |           |           |                                     |
| Relative Humidity                         | 0~100%                                          | 0~100%    | 0~100%    | 0~100%                              |
| Max. Operating Altitude (m)               | 4000                                            |           |           |                                     |
| Cooling Method                            | Smart Fan Cooling                               |           |           |                                     |
| User Interface                            | LED, LCD (Optional) , WLAN+APP                  |           |           |                                     |
| Communication                             | RS485, WiFi or 4G (Optional)                    |           |           | RS485, WiFi or 4G or PLC (Optional) |
| Communication Protocols                   | Modbus-RTU (SunSpec Compliant)                  |           |           |                                     |

| Technical Data                                      | GW100K-HT                                 | GW110K-HT | GW120K-HT | GW136K-HTH |
|-----------------------------------------------------|-------------------------------------------|-----------|-----------|------------|
| Weight (kg)                                         | 93.5                                      | 98.5      | 98.5      | 98.5       |
| Dimension (W×H×Dmm)                                 | 1008× 678× 343                            |           |           |            |
| Noise Emission (dB)                                 | <70                                       | <70       | <70       | <70        |
| Topology                                            | Non-isolated                              |           |           |            |
| Self-consumption at Night (W)                       | < 2                                       |           |           |            |
| Ingress Protection Rating                           | IP66                                      |           |           |            |
| Anti-corrosion Class                                | C5 (Optional)                             |           |           |            |
| DC Connector                                        | MC4 (4~6mm <sup>2</sup> )                 |           |           |            |
| AC Connector                                        | OT/DT terminal (Max. 300mm <sup>2</sup> ) |           |           |            |
| Environmental Category                              | 4K4H                                      |           |           |            |
| Pollution Degree                                    | III                                       |           |           |            |
| Overvoltage Category                                | DCII / ACIII                              |           |           |            |
| Protective Class                                    | I                                         |           |           |            |
| The Decisive Voltage Class (DVC)                    | PV: C<br>AC: C<br>com: A                  |           |           |            |
| Active Anti-islanding Method                        | AQDPF                                     |           |           |            |
| Country of Manufacture (only for Australian market) | China                                     |           |           |            |

**NOTE:**

\*1: For Australia is 99.99kW/kVA

\*2: For Brazil Nominal Output Voltage (V): 380, 3L/N/PE or 3L/PE

\*3: When the input voltage is between 1000V and 1100V, the inverter enters the waiting mode. When the voltage returns to 180V to 1000V, the inverter will resume normal operation.

| Technical Data                                                   | GW73KLV-HT                      | GW75K-HT                    | GW80K-HT    |
|------------------------------------------------------------------|---------------------------------|-----------------------------|-------------|
| <b>Input</b>                                                     |                                 |                             |             |
| Max.Input Power (kW)                                             | 112.5                           | 112.5                       | 120         |
| Max.Input Voltage (V)                                            | 800                             | 1100*2                      | 1100*2      |
| MPPT Operating Voltage Range (V)                                 | 180~650                         | 180~1000                    | 180~1000    |
| MPPT Voltage Range at Nominal Power (V)                          | 250~650                         | 500~850                     | 500~850     |
| Start-up Voltage (V)                                             | 200                             | 200                         | 200         |
| Nominal Input Voltage (V)                                        | 370                             | 600                         | 600         |
| Max. Input Current per MPPT (A)                                  | 30                              | 30                          | 30          |
| Max. Short Circuit Current per MPPT (A)                          | 45                              | 45                          | 45          |
| Max. Backfeed Current to The Array (A)                           | 0                               | 0                           | 0           |
| Number of MPPT                                                   | 12                              | 10                          | 10          |
| Number of Strings per MPPT                                       | 2                               | 2                           | 2           |
| <b>Output</b>                                                    |                                 |                             |             |
| Nominal Output Power (kW)                                        | 73                              | 75                          | 80          |
| Nominal Output Apparent Power (kVA)                              | 73                              | 75                          | 80          |
| Max. AC Active Power (kW)                                        | 69@208V;<br>73@220V;<br>75@230V | 75                          | 88          |
| Max. AC Apparent Power (kVA)                                     | 75                              | 75                          | 88          |
| Nominal Power at 40°C (kW)(Only for Brazil)                      | 73                              | 75                          | 80          |
| Max Power at 40°C (Including AC Overload) (kW) (Only for Brazil) | 73                              | 75                          | 88          |
| Nominal Output Voltage (V)                                       | 220, 3L/N/PE or 3L/PE           | 380/400, 3L/N/PE or 3L/PE*1 |             |
| Output Voltage Range (V)                                         | 187~242                         | 320~440                     |             |
| Nominal AC Grid Frequency (Hz)                                   | 50/60                           | 50/60                       | 50/60       |
| AC Grid Frequency Range (Hz)                                     | 45~55/55~65                     |                             |             |
| Max. Output Current (A)                                          | 192.0                           | 125.3                       | 134.0       |
| Max. Output Fault Current (peak and duration) (A)                | 364@5μs                         | 364@5μs                     | 364@5μs     |
| Inrush Current (peak and duration) (A)                           | 120@1μs                         | 120@1μs                     | 120@1μs     |
| Nominal Output Current (A)                                       | 191.6                           | 114.0/108.3                 | 121.6/115.5 |

| Technical Data                            | GW73KLV-HT                                                     | GW75K-HT | GW80K-HT |
|-------------------------------------------|----------------------------------------------------------------|----------|----------|
| Output Power Factor                       | ~1 (Adjustable from 0.8 leading to 0.8 lagging)                |          |          |
| Max. Total Harmonic Distortion            | <3%                                                            | <3%      | <3%      |
| Maximum Output Overcurrent Protection (A) | 340                                                            | 340      | 340      |
| Efficiency                                |                                                                |          |          |
| Max. Efficiency                           | 98.4%                                                          | 98.6%    | 98.6%    |
| European Efficiency                       | 98.1%                                                          | 98.3%    | 98.3%    |
| Protection                                |                                                                |          |          |
| PV String Current Monitoring              | Integrated                                                     |          |          |
| Internal Humidity Monitoring              | Integrated                                                     |          |          |
| PV Insulation Resistance Detection        | Integrated                                                     |          |          |
| Residual Current Monitoring               | Integrated                                                     |          |          |
| PV Reverse Polarity Protection            | Integrated                                                     |          |          |
| Anti-islanding Protection                 | Integrated                                                     |          |          |
| AC Overcurrent Protection                 | Integrated                                                     |          |          |
| AC Short Circuit Protection               | Integrated                                                     |          |          |
| AC Overvoltage Protection                 | Integrated                                                     |          |          |
| DC Switch                                 | Integrated                                                     |          |          |
| DC Surge Protection                       | Type II                                                        |          |          |
| AC Surge Protection                       | Type II                                                        |          |          |
| AFCI                                      | Optional                                                       |          |          |
| Remote Shutdown                           | Optional                                                       |          |          |
| PID Recovery                              | Optional                                                       |          |          |
| PID Recovery                              |                                                                |          |          |
| Operating Temperature Range (°C)          | -30 ~ 60 (60 °C for outdoor unconditioned with solar effects.) |          |          |
| Relative Humidity                         | 0~100%                                                         |          |          |
| Max. Operating Altitude (m)               | 5000 (>4000 derating)                                          |          |          |
| Cooling Method                            | Smart Fan Cooling                                              |          |          |
| Display                                   | LED, LCD (Optional) ,WLAN+APP                                  |          |          |
| Communication                             | RS485, WiFi or 4G (Optional)                                   |          |          |
| Communication protocols                   | Modbus-RTU (SunSpec Compliant)                                 |          |          |
| Weight (Kg)                               | 98.5                                                           | 93.5     | 93.5     |
| Dimension (W×H×Dmm)                       | 1008× 678× 343                                                 |          |          |

| Technical Data                   | GW73KLV-HT                   | GW75K-HT | GW80K-HT |
|----------------------------------|------------------------------|----------|----------|
| Noise Emission (dB)              | <70                          | <70      | <70      |
| Topology                         | Non-isolated                 |          |          |
| Self-consumption at Night (W)    | <2                           |          |          |
| Ingress Protection Rating        | IP66                         |          |          |
| Anti-corrosion Class             | C5 (Optional)                | C4       |          |
| DC Connector                     | MC4 (4~6mm²)                 |          |          |
| AC Connector                     | OT/DT terminal (Max. 300mm²) |          |          |
| Environmental Category           | 4K4H                         |          |          |
| Pollution Degree                 | III                          |          |          |
| Overvoltage Category             | DC II / AC III               |          |          |
| Protective Class                 | I                            |          |          |
| The Decisive Voltage Class (DVC) | PV: C<br>AC: C<br>com: A     |          |          |
| Active Anti-islanding Method     | AQDPF+AFDPF                  |          |          |
| Country of Manufacture           | China                        |          |          |

**NOTE:**

\*1: For Brazil Nominal Output Voltage (V): 380, 3L/N/PE or 3L/PE

\*2: When the input voltage is between 1000V and 1100V, the inverter enters the waiting mode. When the voltage returns to 180V to 1000V, the inverter will resume normal operation.

# 11 Term Explanation

## Overvoltage category definition

**Category I:** Applies to equipment connected to a circuit where measures have been taken to reduce transient overvoltage to a low level.

**Category II:** Applies to equipment not permanently connected to the installation. Examples are appliances, portables tools and other plug-connected equipment.

**Category III:** Applies to a fixed equipment downstream, including the main distribution board. Examples are switchgear and other equipment in an industrial installation.

**Category IV:** Applies to equipment permanently connected at the origin of an installation (upstream of the main distribution board). Examples are electricity meters, primary over-current protection equipment and other equipment connected directly to outdoor open lines.

## Moisture location category definition

| Parameters          | Level     |             |             |
|---------------------|-----------|-------------|-------------|
|                     | 3K3       | 4K2         | 4K4H        |
| Moisture Parameters | 0 - +40°C | -33 - +40°C | -33 - +40°C |
| Temperature Range   | 5% - 85%  | 15% - 100%  | 4% - 100%   |

## Environment category definition

**Outdoor:** Ambient Temperature: -25~+60°C, applied to Pollution Degree 3 environment.

**Indoor Unconditioned:** Ambient Temperature: -25~+40°C, applied to Pollution Degree 3 environment.

**Indoor conditioned:** Ambient Temperature: 0~+40°C, applied to Pollution Degree 2

**environment. Outdoor:** Ambient Temperature: 0~+40°C, applied to Pollution Degree 2 environment.

## Pollution degree definition

**Pollution Degree I:** No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.

**Pollution Degree II:** Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.

**Pollution Degree III:** Conductive pollution occurs, or dry, non-conductive pollution occurs, which becomes conductive due to condensation, which is expected.

**Pollution Degree IV:** Persistent conductive pollution occurs, for example, the pollution caused by conductive dust, rain or snow.



GoodWe Website

## **GoodWe Technologies Co., Ltd.**

---

 No. 90 Zijin Rd., New District, Suzhou, 215011, China

 [www.goodwe.com](http://www.goodwe.com)

 [service@goodwe.com](mailto:service@goodwe.com)



Local Contacts