



User Manual

Smart Data Logger EzLogger Pro

V1.2-2023-12-20

Table of Contents

| | |
|---|----|
| Chapter I: Safety Precautions | 01 |
| 1.1 Safety Instructions | 01 |
| 1.2 Schematic Symbols | 01 |
| Chapter II: Product Introduction | 02 |
| 2.1 Product Introduction | 02 |
| 2.2 Appearance Description | 02 |
| 2.3 Description of LED Indicators | 06 |
| Chapter III: Equipment Installation | 08 |
| 3.1 Packaging Information | 08 |
| 3.2 Equipment Installation | 09 |
| Chapter IV: Electrical Connection | 11 |
| 4.1 Port Description | 11 |
| 4.2 Connection to the Inverter | 12 |
| 4.3 Connection to the Environmental Monitor and Meter | 15 |
| 4.4 Connection to the Computer | 16 |
| 4.5 Connection to the Ripple Control Receiver/DREDr | 18 |
| Chapter V: LAN EzLogger Pro Data Upload and Function Configuration .. | 19 |
| 5.1 How to Use LAN EzLogger Pro | 19 |
| 5.2 EzLogger Pro Configuration | 20 |
| 5.3 Program Upgrade | 29 |
| Chapter VI : Website Monitoring | 30 |
| 6.1 Register A New User and Add A Power Station | 30 |
| 6.2 View Power Station Information | 31 |
| Chapter VII : Technical Specifications | 33 |
| Chapter VIII : Certificationand Warranty | 34 |
| 8.1 Certification Mark | 34 |
| 8.2 Warranty Certificate | 34 |
| 8.3 Warranty Conditions | 34 |
| 8.4 Disclaimer | 34 |










Chapter I: Safety Precautions

1.1 Safety Instructions

EzLogger Pro produced by GoodWe Technologies Co., Ltd. (hereinafter “GoodWe”) is designed and tested in strict accordance with the relevant safety regulations, however, as an electrical and electronic device, the following safety instructions shall be followed at the time of installation and maintenance, improper operation will cause personal injury and property damage to the operator and third party.

- 1. Prevent children from approaching EzLogger Pro.
- 2. Do not open the upper cover, unauthorized touching or replacement of components may cause personal injury and damage to EzLogger Pro, in this case, GoodWe will not be liable for such injury or damage or quality warranty.
- 3. Static electricity may damage electronic components, so appropriate measures shall be taken to prevent static electricity.

1.2 Schematic Symbols

| | |
|---|--|
|  | Minor or moderate injury may be caused |
|  | It shall not be disposed of as ordinary waste, a special route is required for recycling |
|  | Keep upright, and do not tilt or put upside down |
|  | Recyclable |
|  | Fragile! Handle with care |
|  | Keep away from moisture |
|  | CE mark |
|  | Points of attention |
|  | Explanation |

Chapter II: Product Introduction



Introduce the appearance and function of EzLogger Pro.

2.1 Product Introduction



Introduce the main functions of EzLogger Pro.

EzLogger Pro is a dedicated device for the photovoltaic power generation system monitoring and management platform, which achieves interface aggregation, data acquisition, data storage, centralized monitoring, centralized maintenance and other functions for the inverters, environmental monitor, watt-hour meter and other devices in the photovoltaic power generation system.

2.2 Appearance Description



Introduce the appearance, specifications and ports of EzLogger Pro.





Figure 2.2-1 External View of EzLogger Pro

Front of the box



Side of the box






Figure 2.2-3 Side View of EzLogger Pro Box

| No. | Port | Port Description |
|-----|-------------|---|
| 1 | Sound alarm | Buzzer sound hole |
| 2 | Micro SD | SD memory card slot |
| 3 | USB | USB slot |
| 4 | Reload | Switch the IP mode of the EzLogger Pro <ul style="list-style-type: none">Long press the button for 10s to switch the EzLogger Pro from dynamic IP mode to static IP mode. The indicator lights up from right to left after switching the mode.Long press the button for 3s to switch the EzLogger Pro from static IP mode to dynamic IP mode. The indicator lights up from left to right after switching the mode. |

Back of the box




Bottom surface of the box



| No. | Port | Port Description |
|-----|-------|--|
| 1 | POWER | Adapter 12VDC input |
| 2 | NET | Ethernet port |
| 3 | DI | DRED or RCR function port |
| 4 | NC | Function reserved |
| 5 | COM1 | RS485 communication port 1 for inverter |
| 6 | COM2 | RS485 communication port 2 for inverter |
| 7 | COM3 | RS485 communication port 3 for inverter |
| 8 | COM4 | RS485 communication port 4 for environmental monitor and other devices |

Notice: 1.The DI port of the EzLogger Pro is as follows. REF1 and REF2 occupy two pins.



The DI port of the EzLogger Pro can work as RCR or DRED port in different regions or countries, the definitions are as follows.

| | REF1 | 1 | 2 | 3 | 4 | REF2 |
|------|--------|--------|--------|--------|--------|----------|
| RCR | +5V | D_IN1 | D_IN2 | D_IN3 | D_IN4 | +5V |
| DRED | RefGen | DRM1/5 | DRM2/6 | DRM3/7 | DRM4/8 | Com/DRM0 |

- Do not connect the this port in China as this function cannot work in China.
- 2. COM1, COM2, COM3 can only communicate with the inverter. COM4 can only connect to device like environment monitoring device. Make sure that the ports are connected to right devices.
- 3. For COM1, COM2, COM3, and COM4 ports, A corresponds to the differential signal +, and B corresponds to the differential signal -.

2.3 Description of LED Indicators









Introduce the meaning of the LED indicators.



The LED indicators are as follows:



Figure 2.3-1 Explanatory Drawing of LED Indicators

Description of the LED indicators is as follows:

| Port | Status | Status Description |
|---|---|--|
| <div>POWER</div> <div></div> | Blue light On | Power supply is normal |
| | Blue light Off | No power supply |
| <div>RUN</div> <div></div> | Blue light flashes (1s On/Off alternately) | EzLogger Pro is running properly |
| | Blue light continue On or Off | EzLogger Pro is not running properly |
| <div>SERVER</div> <div></div> | Blue light continue On | EzLogger Pro can communicate with the server properly |
| | Blue light flashes (1s On/Off alternately) | EzLogger Pro is properly connected to the router, but not connected to the external network server |
| | Blue light Off | EzLogger Pro network is not connected |
| <div>PC</div> <div></div> | Blue light On | EzLogger Pro is connected to the computer software ProMate |
| | Blue light Off | EzLogger Pro is not connected to the computer software ProMate |
| <div>COM1</div> <div></div> | Blue light On | Number of inverters actually acquired by EzLogger Pro is equal to the parameter setting |
| | Blue light flashes (1s On/Off alternately) | Number of inverters actually acquired by EzLogger Pro is less than the parameter setting |
| | Blue light flashes (1s On and 3s Off alternately) | Number of inverters to be acquired according to EzLogger Pro the parameter setting is not set |
| | Blue light Off | No inverter data acquired by EzLogger Pro |
| <div>COM2</div> <div></div> | Blue light On | Number of inverters actually acquired by EzLogger Pro is equal to the parameter setting |
| | Blue light flashes (1s On/Off alternately) | Number of inverters actually acquired by EzLogger Pro is less than to the parameter setting |
| | Blue light flashes (1s On and 3s Off alternately) | Number of inverters to be acquired according to EzLogger Pro parameter setting is not set |
| | Blue light Off | No inverter data acquired by EzLogger Pro |

| | | |
|---|---|---|
| COM3  | Blue light On | Number of inverters actually acquired by EzLogger Pro is equal to that to the parameter setting |
| | Blue light flashes (1s On/Off alternately) | Number of inverters actually acquired by EzLogger Pro is less than the parameter setting |
| | Blue light flashes (1s On and 3s Off alternately) | Number of inverters to be acquired according to EzLogger Pro parameter setting is not set |
| | Blue light Off | No inverter data acquired by EzLogger Pro |
| COM4  | Blue light On | Communication of external environmental monitor and other devices is normal |
| | Blue light Off | Not connected to external device like environmental monitor. Or the ProMate settings is not configured. |

Chapter III: Equipment Installation



Introduce the packaging information and installation process of EzLogger Pro.

3.1 Packaging Information



Introduce the packaged accessories of EzLogger Pro.

After opening the EzLogger Pro package, please check whether the accessories are complete and there is any apparent damage. If there is any damage or certain items are missing, please contact your dealer.

Delivery diagram of accessories:




EzLogger Pro x1




Power adapter x1^[1]



Guide rail x1




Wiring terminal xN^[2]



Expansion screw x2



Documents x1



[1]: Power adapter models will be determined according to the safety regulations of export destination countries.

[2]: N: 2 in China and 4 in areas except China.

3.2 Equipment Installation



Introduction the installation process of EzLogger Pro.

3.2.1 Choose the installation location

The following points shall be considered when you select the installation location:

1. The ingress protection rating of EzLogger Pro is IP20, so it has no waterproof performance and is for indoor use only.
2. The installation method and location shall be suitable for the weight and size of EzLogger Pro.
3. The installation location shall be well-ventilated away from direct sunlight, and ensure the ambient temperature is within the range of -20°C ~ 60°C.

3.2.2 Install EzLogger Pro

There are three installation methods for EzLogger Pro, namely, table surface mounting, wall mounting and rail mounting.

Installation method 1: Table surface mounting



Please select the table surface mounting method for EzLogger Pro so as not avoid damage to EzLogger Pro due to falling. Do not put EzLogger Pro in a location where it touches cables easily so as to avoid signal interruption due to cable touching.

Installation method 2: Wall mounting

Steps:

1. Drill two circular holes in the wall. The distance between the two circular holes is 70mm, the hole diameter is 8mm, and the screw head protrudes 4mm.
2. Hang the wall mounting holes on the back of EzLogger Pro onto the screws.




Figure 3.2.2-1 Schematic Diagram of Wall Mounting of EzLogger Pro

Installation method 3: Rail mounting

Steps:

1. Drill two circular holes in the wall, the distance between the two circular holes is 100mm, the hole diameter is 8mm, and the hole depth is 40mm.
2. Install the guide rail on the wall.
3. Install EzLogger Pro on the guide rail.




Figure 3.2.2-2 Schematic Diagram of Rail Mounting

Chapter IV: Electrical Connection



Introduce how EzLogger Pro is electrically connected to the inverter, computer, environmental monitor, meter and other devices.

4.1 Port Description



Introduce the ports of EzLogger Pro for connection with the inverters and their functions.

The schematic diagram of the ports on the bottom surface of EzLogger Pro is as follows:





Figure 4.1-1 Schematic Diagram of Ports on the Bottom Surface of Ezlogger Pro

The ports on the bottom surface of EzLogger Pro are described as follows:

| No. | Port | Port Description |
|-----|-------|--|
| 1 | POWER | Adapter 12VDC input |
| 2 | NET | Ethernet port |
| 3 | DI | DRED or RCR function port |
| 4 | NC | Function reserved |
| 5 | COM1 | RS485 communication port 1 for inverter |
| 6 | COM2 | RS485 communication port 2 for inverter |
| 7 | COM3 | RS485 communication port 3 for inverter |
| 8 | COM4 | RS485 communication port 4 for environmental monitor and other devices |



1. Below is the diagram of EzLogger Pro DI ports, where REF1 and REF2 occupy two ports respectively.



EzLogger Pro DI ports are compatible with RCR and DRED functions, and the ports for different functions are defined as follows:

| | REF1 | 1 | 2 | 3 | 4 | REF2 |
|------|--------|--------|--------|--------|--------|----------|
| RCR | +5V | D_IN1 | D_IN2 | D_IN3 | D_IN4 | +5V |
| DRED | RefGen | DRM1/5 | DRM2/6 | DRM3/7 | DRM4/8 | Com/DRM0 |

2. COM1, COM2 and COM3 only communicate with the inverters, and COM4 is only connected to the environmental monitor and other devices, so avoid wrong correction.
3. A of COM1, COM2, COM3 and COM4 ports corresponds to the differential signal +, B corresponds to the differential signal -.

4.2 Connection to the Inverter



Introduce how EzLogger Pro is connected to the inverter.

4.2.1 Connection to a single inverter



Introduce RS485 communication connection mode between EzLogger Pro and the inverter.

Through RS485, the inverter is connected to EzLogger Pro for communication, and EzLogger Pro has 3 RS485 ports, namely COM1, COM2 and COM 3.

The diagram of COM1, COM2 and COM3 ports of EzLogger Pro is as follows:




Figure 4.2.1-1 Schematic Diagram of COM1, COM2 and COM3 Ports of EzLogger Pro

COM ports are described as follows:

| Port | Symbol | Description |
|------|--------|-------------------------------------|
| COM1 | A | RS485A, RS485 differential signal + |
| | B | RS485B, RS485 differential signal - |
| COM2 | A | RS485A, RS485 differential signal + |
| | B | RS485B, RS485 differential signal - |
| COM3 | A | RS485A, RS485 differential signal + |
| | B | RS485B, RS485 differential signal - |




Figure 4.2.1-2 Wiring Diagram of EzLogger Pro COM Ports

Steps:

1. Select a RS485 communication cable of appropriate length ($\leq 1000\text{m}$).
2. First strip off the insulating layer at both ends of the communication cable.
3. Then connect one core of the communication cable with terminal A of EzLogger Pro COM port, and the other core with terminal B of EzLogger Pro COM port.
4. Another side connect to inverter, please refer to the meaning of RS485 port of inverter.

Note that COM"A" of Ezlogger Pro connect to the RS485"A" of inverter, COM"B" of Ezlogger Pro connect to the RS485"B" of inverter.



1. RS485 communication cable shall be a standard RS485 communication shielded twisted pair wire.
2. Inverter communication cable can only be connected to EzLogger Pro's COM1, COM2 and COM3.
3. A single COM port of EzLogger Pro supports a maximum of 20 inverters, and 3 COM ports support a total of 60 inverters.



Description of connection of communication cable with the terminal block:

1. First press and hold the corresponding orange contact sheet of the wiring terminal to spring up the elastic metal sheet of the wiring terminal.
2. Insert the stripped portion of the wire cores into the terminal.
3. Release the orange contact sheet to fasten the wire cores.





Figure 4.2.1-3 Wiring of EzLogger Pro COM port

4.2.2 Connection to multiple inverters



Introduce how EzLogger Pro is connected to multiple inverters.

When EzLogger Pro is connected to multiple inverters, “hand-in-hand” connection method can be used; each inverter has two multiplexed RS485 communication ports, and one RS485 port of the inverter is connected to one RS485 port of the next inverter. Note that port A shall correspond to Port A, and Port B shall correspond to Port B. The number of inverters connected to a single COM port shall not exceed 20, and number of inverters connected to three ports shall not exceed 60.




4.3 Connection to the Environmental Monitor and Meter



Introduce how EzLogger Pro is connected to the environmental monitor and meter.

When EzLogger Pro is connected to the environment monitor , meter and other devices, COM4 port shall be used.

Schematic diagram of COM4 port is as follows:



Description of COM4:

| Port | Symbol | Description |
|------|--------|-------------------------------------|
| COM4 | A | RS485A, RS485 differential signal + |
| | B | RS485B, RS485 differential signal - |

Steps:

1. connect one end of the communication line to the RS485 port of the environment monitor and the meter.
2. connect the other end of the communication line to the COM4 port of EzLogger Pro.



Please make sure that the RS485 + of the environmental monitor and meter is connected to COM4 "A" of EzLogger Pro, and the RS485 - of the environmental monitor and meter is connected to COM4 "B" of EzLogger Pro. Environmental monitor, meter and other devices can only be connected to COM4.

4.4 Connection to the Ripple Control Receiver/DRED



Introduce the functions of Ripple Control Receiver.

In Germany and parts of Europe, power grid companies use ripple control receivers to convert power grid scheduling signals for dry contact transmission, and power stations need to use dry contact communication method to receive power grid scheduling signals.

According to the Australian safety regulations, power grid companies use DRED to convert power grid scheduling signals for dry contact transmission, and power stations need to use dry contact communication method to receive power grid scheduling signals.

EzLogger Pro is connected to DRED or ripple control receiver using the same port, and the port is defined as follows when DRED function is used.




Figure 4.4-1 Schematic Diagram of EzLogger Pro DI Port

Ripple Control Receiver (RCR): provides RCR signal control port to meet power grid scheduling requirements in regions such as Germany.

| Functin | Port | Silkscreen | Definition |
|-----------------------|------|------------|------------|
| RCR(only for German) | DI | REF1 | +5V |
| | | 1 | D_IN1 |
| | | 2 | D_IN2 |
| | | 3 | D_IN3 |
| | | 4 | D_IN4 |
| | | REF2 | +5V |

Short circuit the RCR port as follows:

| | 1 | 2 | 3 | 4 |
|------|------|---------|--------|---------|
| REF1 | 100% | 60% | 30% | 0% |
| REF2 | PF=1 | PF=0.95 | PF=0.9 | PF=0.85 |

EzLogger Pro is connected to the ripple control receiver as follows:




Figure 4.4-2 Diagram of Connection of EzLogger Pro DI Port to RCR

DRED (Demand Response Enabling Device) : provides DRED signal control port to meets DRED requirements in regions like Australia.

| Function | Port | Silkscreen | Definition |
|--------------------------|------|------------|------------|
| DRED(only for Australia) | DI | REF1 | RefGen |
| | | 1 | DRM1/5 |
| | | 2 | DRM2/6 |
| | | 3 | DRM3/7 |
| | | 4 | DRM4/8 |
| | | REF2 | Com/DRM0 |

Steps:

1. Select a cable of appropriate length, and connect one end of the cable with the ripple control receiver.
2. Connect the other end of the cable with the corresponding DI port of EzLogger Pro, and refer to Section 4.2.1 Inverter RS485 communication connection method for detailed connection.




Figure 4.4-3 Wiring of EzLogger Pro DI port

4.5 Connection to the Computer



Introduce how EzLogger Pro is connected to the computer.

Steps:

1. Insert one end of the network cable into the "NET" port of EzLogger Pro.
2. Insert the other end of the cable into the computer's Ethernet port.



When connecting to the computer, you need to use ProMate commissioning software. Please refer to 5.1 for ProMate software settings.

Chapter V: LAN EzLogger Pro Data Upload and Function Configuration



Introduce LAN EzLogger Pro monitoring data transmission and the configuration method.


5.1 How to Use LAN EzLogger Pro



Introduce LAN EzLogger Pro monitoring data transmission.

After EzLogger Pro is connected to the collected data, one should connect EzLogger Pro to the Internet, so that EzLogger Pro can upload the collected data to the server. Dynamic IP (DHCP) is a default function for EzLogger Pro.

- If the network device is in dynamic IP mode(DHCP), switch the EzLogger Pro to static IP mode and connect the EzLogger Pro to the PC to configure the parameters using the ProMate software. After the configuration, switch the EzLogger Pro to dynamic IP mode. Then connect the NET port of EzLogger Pro directly to the LAN port of the router, and enable the dynamic IP (DHCP) function of the router. EzLogger Pro can connect to the network and automatically upload the collected data to the monitoring platform.
- If the network device is in static IP mode, switch the EzLogger Pro to static IP mode and connect the EzLogger Pro to the PC to configure the parameters using the ProMate software. Modify network information such as the IP address of the EzLogger Pro to enable the communication between the EzLogger and network device. Then connect the NET port of EzLogger Pro directly to a network device, such as the LAN port of the switch. EzLogger Pro can connect to the network and automatically upload the collected data to the monitoring platform.



5.2 EzLogger Pro Configuration



Introduce how to use ProMate to configure EzLogger Pro.

5.2.1 Connecting ProMate to EzLogger Pro

ProMate software is launched by us for functional configuration of EzLogger Pro, by which we can realize modification to the IP address of EzLogger Pro, quantity setting of connected inverters for port, time setting, sound and light alarm, RCR, DRED enabling configuration, field debugging, etc. Firstly, the user needs to install "ProMate" software in the computer. Please access to GoodWe official website and search for "ProMate" to download the program and complete the installation.

1. Configuration Method for EzLogger Pro Static IP Address:

If the user has a static IP, it is necessary to switch EzLogger Pro to the static IP mode. That is, press the Reload key for about 10 seconds to reset and restart EzLogger Pro, The LEDs on EzLogger Pro will blink one after another from right to left. After restart, EzLogger Pro will be switched to static IP mode(default IP:192.168.1.200),then modify the computer's IP address, take WIN7 as an example, the steps are as below. The user can find the methods from the Internet for modifying IP addresses of different computer systems.

- (1) Switch EzLogger Pro to static IP, then use cables to connect EzLogger Pro "NET" port to the Ethernet port of the computer.
- (2) Turn on the computer, right click on "Network " on the desktop, and click on "Properties".




Figure 5.2-1 Open the Network Connections Window

(3) Click on "Change adapter settings".




Figure 5.2-2 Modification of Adapter Configuration

(4) Pop up the local connection dialog box, right-click on "Local Connection" and then click on "Properties".




Figure 5.2-3 Modification of the Properties of Local Connections

Pop up a dialog box as below:



Figure 5.2-4 Modification of Internet Protocol 4 (TCP/IPv4)

(5) Double click on "Internet Protocol 4 (TCP/IPv4)" to pop up the "Properties" dialog box of "Internet Protocol 4 (TCP/IPv4)", then complete the setting for the dialog box in accordance with the following requirements.

The defaulted IP address for EzLogger Pro is 192.168.1.200. In order to put your computer and EzLogger Pro under the same network segment, you should set the IP address and the default gateway in 192.168.1. XXX network segment ($1 \leq XXX \leq 250$ and $XXX \neq 200$).

For example:

The user can set the IP address as 192.168.1.100 and the default gateway as 192.168.1.254.




Figure 5.2-5 Modification of the IP Address

Click “Connect” button in ProMate to connect ProMate to EzLogger Pro, and the system will indicate “The connection is successful”, as shown in Figure 5.2-6.




Figure 5.2-6 Connection between ProMate Software and EzLogger Pro in Static IP

5.2.2 Quantity Configuration for Inverter Communication Port

Terminal configuration is used for setting EzLogger Pro's COM1, COM2, COM3 ports which the quantity of inverters connecting, assume port 1 (corresponding communication port COM1) connecting the quantity of inverters is 2, then check port 1, the quantity settings is 2, click on "Set" button to finish the configuration. As picture 5.2-7.



Figure 5.2-7 Parameter Configuration

Please set the quantity of devices of each port according to the quantity of inverters actually connected. Upon the completion of setting, the user can check the actual communication status of inverter from the LED indicator of EzLogger Pro (see Section 2.3 LED Indicator).

5.2.3 Time Setting

Time setting will synchronize the time of EzLogger Pro and inverter and the time of synchronization server. Click on “Set Time” to pop up the following dialog box, as shown in the figure below. Then click on “OK” after setting the time, as shown in Figure 5.2-8.




Figure 5.2-8 Time Setting

5.2.4 DRED setting

DRED function can control the inverter's generated power according to power grid control signal, only apply to Australia and New Zealand. Before start using DRED function, it will have to connect electricity meter well first and set inverter's safety country, then set installation capacity and CT current ratio .etc parameters. Below instructions are installation capacity and CT current ratio:

1. Installation capacity: The inverter's sum of rated generate electricity, such as there are 2 pieces of 10KW inverters on site, then the installation capacity is to set 20KW, calculate method is $2 \times 10KW$.
2. CT current ratio: Current transformer labeled input and output current ratio. For example, labeled ratio was 200/5, then CT current ratio setting is 40. Click “Start Using DRED” button after setting finished to achieve the configuration. As picture 5.2-13 showed.




Figure 5.2-9 Enable DERD

After start using successfully,the “ Refresh ” column will display.




Figure 5.2-10 Real Time Data

Meter power means: The electricity meter measure the grid power, display positive value means the user sell electricity power value, display negative value means the user buy electricity power value.

Inverters power means: All of the inverters' sum of generate electricity power value.

Load power means: Load consumption power.

When start using DRED function , if EzLogger Pro detects inverter had earth fault,then it will trigger sound-light alarm function:buzzer will ring for 1 minute,and RUN LED will be lighting for 1 minute. After 1 minute,the alarm will stop and keep on detecting every 30 minutes until fault disappearing.

5.2.5 RCR setting

RCR function only apply to Germany.If the customer needs to start using RCR function,please set inverter's safety country first,then check "Enable" to enable RCR function.As picture 5.2-15.




Figure 5.2-11 RCR Setting

5.2.6 Field Debugging

ProMate can also be applied to field installation and debugging. After installation is completed, click on "Refresh" to show whether the inverter is online or not. If the system prompts "off line", please check whether the connection cable has any problem, and then timely solve the problems till the system shows that all the inverter are "on line". It should be noted that it takes time to get the inverter status due to communication rate problems, as shown in Figure 5.2-12.




Figure 5.2-12 Acquiring the Inverter Status

5.2.6 (Optional) Modification to the IP address of EzLogger Pro

The user can adopt the required configuration after connecting ProMate software to EzLogger Pro.

In static IP mode, the user can configure IP address, subnet mask, gateway and DNS that can be accessed to Internet as required, as shown in Figure 5.2-8.

For example:

The User's IP Address 192.168.8.115 The User's Gateway 192.168.8.1
The User's Subnet Mask 255.255.255.0 The User's DNS 8.8.8.8

Put the above data into LAN configuration, and then click the "Set" button to complete the set. Now IP address of EzLogger Pro has been modified as the configuration as required by the user, and physical connection between EzLogger Pro and ProMate can be disconnected after the configuration is completed. Then the Internet will be available just by plugging Ethernet cable into EzLogger Pro.




Figure 5.2-13 Modification to LAN Configuration

5.3 Program Upgrade



Introduction to local and remote upgrade method of EzLogger Pro.

5.3.1 Upgrade EzLogger Pro

- (1) Local Upgrade: Put the bin files required by upgrade in the root directory of U disk (please use the U disk with 2.0 port, FAT32 format), insert the USB flash disk in to the USB port of EzLogger Pro, cut off the electricity to EzLogger Pro and then repower it, so as to enable automatic update of the program.



The bin files for program upgrade is named as "EzLoggerPro_new.bin". Bin files will be sent to client via E-mail. And the client shall save the received bin files in root directory of U disk, and check whether the file name is "EzLoggerPro_new.bin" or not. If not, please change into this name, otherwise inconsistent file names will cause the failure of the program upgrade. The shining of all of the eight indicator lights of EzLogger Pro in the program upgrade process indicates that the program is upgrading; the indicator lights will restore to the normal state when the program upgrade is completed. It is forbidden to cut off electricity in the program upgrade process.

(2) Remote Upgrade: Upgrade program is uploaded to the server by GOODWE in the background, so as to enable automatic check and update of EzLogger Pro.

Chapter VI : Website Monitoring



Introduce the registration, setting and monitoring methods for website monitoring.

6.1 Register A New User and Add A Power Station

The data acquisition terminal operates data via RS485 inverter acquisition. The data is uploaded to the server via Ethernet, and the user can log onto the monitoring platform to browse data and operating state information, and the monitoring platform website is <https://www.semsportal.com/Home/Login>. The following describes how to register and add power station information when the user logs on for the first time.

Step 1: Open the browser, then visit <https://www.semsportal.com/Home/Login>, and you can enter GOODWE monitoring platform homepage. Click **Language-English** to select language. Then log in using the



account of the administrator or installer.
Log in use administrator's account or installer's account created by upper level organization, like by dealers. Refer to **SEMS Portal User Manual** if you want to create an organization or an account.

Step 2: Create a PV plant, Select **Management > Plants**. Click **Create**.

G10014687Pv plantJ677

Owner : Add

| Email | Operation |
|-------------------------------|-----------|
| Please add owner information. | |

Visitor : Add

| Email | Operation |
|---------------------------------|-----------|
| Please add visitor information. | |

Plant Info :

+

*Plant Name: *Capacity: kW

Classification: Distributor code: Keep it empty if you don't know the installer's code

*Profit Ratio: USD/kWh Amount of solar panels:

*Location: Map

Detailed Address:

Enable Profile: ☒ Enable ☐ Disable Creation Date:

Plant Profile
Distributed PV power plant refers to the operation mode of "construction and operation at the user's site or nearby, and implementation of "self-use, excess power to grid, energy consumption and power grid adjustment" on the use side and in the distribution network system, the characteristics of photovoltaic power generation facilities are balanced and adjusted. Distributed photovoltaic power generation follows the principle of adapting to local conditions, clean and highly efficient, decentralized layout, and proximity utilization, making full use of local solar energy resources to replace and reduce fossil energy consumption. Without the use of fuel, the operating cost is very low; there are no moving parts, it is not easy to damage, maintenance is simple, especially suitable for use in understudied conditions; it will not produce any waste, no pollution, noise and other public hazards, no adverse impact on the environment. Outstanding environmental benefits. Distributed photovoltaic power generation is a new type of power generation and energy comprehensive utilization mode with broad development prospects. It can realize nearly power supply without long distance transmission.

Cancel Register

Figure 6.1-1 Create a PV Plant

Step 3: Add an EzLogger Pro in the PV plant. Click **Management > Plants**, select the corresponding PV plant and click **Device Management**.




Figure 6.1-2 Add the Device

6.2 Check the PV Plant

Check the power generation status and equipment information via SEMS Portal after adding the equipment to the monitoring platform.

Step 1: Enter <https://www.semsportal.com/Home/Login>, and log in using administrator/installers/guest account.

Step 2: Click the plant name as figure 6.2-1 below.




Figure 6.2-1 Check the PV Plant

Step 3: Check the detailed information of the plant.




Figure 6.1-3 Plant Information

Chapter VII : Technical Specifications



Introduce the technical indicators of EzLogger Pro.

| Model | Ezlogger Pro | |
|---------------------------|-------------------------------------|---|
| Communication Management | | |
| Communication | Inverter Communication | 3 x RS485 |
| | Third-party equipment communication | 1 x RS485 |
| | Ethernet Communication | 10/100M |
| Number of Managed Devices | RS485 | 60 (The number of devices connected to a single RS485 port shall not exceed 20) |
| Communication Distance | RS485 (m) | 1000 (Shielded twisted pair wire shall be used) |
| | Ethernet (m) | 100 |
| General Parameters | | |
| General Parameters | Power Adapter | Input: 100~240Vac, 50/60Hz; |
| | output: 12Vdc 1.5A; | |
| | Power Consumption (W) | General 3, Maximum 6 |
| | Storage Capacity | 16MB, expandable to 8GB through an optional SD card |
| | Dimensions (L * W * H mm) | 190*118*37 |
| | Weight (g) | 500 |
| | Operating Temperature Range (°C) | -20 ~ +60 |
| | Relative Humidity | 5% ~ 95% (non-condensing) |
| | Ingress Protection Rating | IP20 |
| | Installation Methods | Wall mounting, table surface mounting, rail mounting |
| | User Interface | 8 LED indicators |

Chapter VIII : Certification and Warranty

8.1 Certification Mark



8.2 Warranty Certificate

The users shall keep the product warranty card and purchase invoice properly in the product warranty period, and also keep the product nameplate legible; otherwise, GoodWe is entitled to refuse to provide quality warranty.

8.3 Warranty Conditions

On the premise that the product is used according to GoodWe User Manual, if any product failure occurs within the warranty period due to quality problems, GoodWe provides the following three ways of warranty according to the actual circumstances:

1. Return the product to the factory for maintenance.
2. On-site maintenance.
3. Product replacement (For discontinued products, it is allowed to replace with the product of equivalent value).

8.4 Disclaimer

The following circumstances are not covered by the warranty:


1. Product or parts have been beyond the warranty period (unless both Parties have signed an agreement for extension of warranty service). Failures or damage caused due to operation in violation of the product manual or relevant installation and maintenance requirements, unsuitable operating environment, improper storage, misuse, etc.
2. Damage caused due to insufficient ventilation. Failure or damage caused due to installation, repair, alteration or disassembly by any person other than GoodWe or the agents and personnel designated by GoodWe.
3. Failure or damage caused due to unforeseen factors, man-induced factors, force majeure or other similar reasons, and other failures or damage not due to GoodWe product quality problems.




GoodWe Website

GoodWe Technologies Co., Ltd.

 No. 90 Zijin Rd., New District, Suzhou, 215011, China

 www.goodwe.com

 service@goodwe.com



340-00657-00 Local Contacts