

# GOODWE



## User Manual

**Hybrid Inverter**  
EH Series/EH Plus Series  
3.6-6kW

V1.7-2024-09-09

**Copyright © GoodWe Technologies Co.,Ltd. 2024. All rights reserved.**

No part of this manual can be reproduced or transmitted to the public platform in any form or by any means without the prior written authorization of GoodWe Technologies Co.,Ltd.

**Trademarks**

**GOODWE** and other GOODWE trademarks are trademarks of GoodWe Technologies Co.,Ltd. All other trademarks or registered trademarks mentioned in this manual are owned by GoodWe Technologies Co.,Ltd.

**Notice**

The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions here are for guidance only.

# CONTENT

- 1 About This Manual..... 1**
  - 1.1 Applicable Model .....1
  - 1.2 Target Audience .....1
  - 1.3 Symbol Definition .....1
- 2 Safety Precaution ..... 2**
  - 2.1 General Safety .....2
  - 2.2 PV String Safety .....2
  - 2.3 Inverter Safety .....3
  - 2.4 Battery Safety .....4
  - 2.5 Personal Requirements .....4
  - 2.6 EU Declaration of Conformity .....4
- 3 Product Introduction ..... 5**
  - 3.1 Product Introduction .....5
  - 3.2 Application Scenarios .....6
  - 3.3 Working Mode .....9
    - 3.3.1 System Working Mode .....9
    - 3.3.3 Inverter Operation Mode .....12
  - 3.4 Features .....13
  - 3.5 Appearance .....14
    - 3.5.1 Parts .....14
    - 3.5.2 Dimension .....14
    - 3.5.3 Indicators .....15
    - 3.5.4 Nameplate .....16
- 4 Check and Storage .....17**
  - 4.1 Check Before Receiving .....17
  - 4.2 Deliverables .....17
  - 4.3 Storage .....18
- 5 Installation .....19**
  - 5.1 Installation Requirements .....19
  - 5.2 Inverter Installation .....22
    - 5.2.1 Moving the Inverter .....22
    - 5.2.2 Installing the Inverter .....22
- 6 Electrical Connection .....24**
  - 6.1 System Wiring Diagram .....24
  - 6.2 Safety Precautions .....26
  - 6.3 Connecting the PE Cable .....26
  - 6.4 Connecting the DC Input Cable (PV) .....27

|           |  |           |
|-----------|--|-----------|
| 6.5       | Connecting the Battery Cable .....                           | 30        |
| 6.6       | Connecting the AC Cable .....                                | 32        |
| 6.6.1     | Connecting the AC Cable (ON-GRID) .....                      | 33        |
| 6.6.2     | Connecting the AC Cable (BACK-UP) .....                      | 34        |
| 6.7       | Communication Connection .....                               | 36        |
| 6.7.1     | Connecting the Communication Cable.....                      | 36        |
| 6.7.2     | Connecting BMS or Meter Communication Cable (Optional) ..... | 37        |
| 6.7.3     | Installing the Communication Module (Optional).....          | 39        |
| <b>7</b>  | <b>Equipment Commissioning .....</b>                         | <b>40</b> |
| 7.1       | Check Before Power ON.....                                   | 40        |
| 7.2       | Power On.....  | 40        |
| <b>8</b>  | <b>System Commissioning.....</b>                             | <b>41</b> |
| 8.1       | Indicators and Buttons .....                                 | 41        |
| 8.2       | Setting Inverter Parameters via SolarGo App .....            | 42        |
| 8.3       | Monitoring via SEMS Portal .....                             | 42        |
| <b>9</b>  | <b>Maintenance .....</b>                                     | <b>43</b> |
| 9.1       | Power OFF the Inverter .....                                 | 43        |
| 9.2       | Removing the Inverter .....                                  | 43        |
| 9.3       | Disposing of the Inverter .....                              | 44        |
| 9.4       | Troubleshooting.....   | 45        |
| 9.5       | Routine Maintenance.....                                     | 52        |
| <b>10</b> | <b>Technical Parameters.....</b>                             | <b>53</b> |

# 1 About This Manual

This manual describes the product information, installation, electrical connection, commissioning, troubleshooting, and maintenance. Read through this manual before installing and operating the product. All the installers and users have to be familiar with the product features, functions, and safety precautions. This manual is subject to update without notice. For more product details and latest documents, visit <https://en.goodwe.com>.

## 1.1 Applicable Model

This manual applies to the listed inverters below:




| Model         | Nominal Output Power | Nominal Output Voltage |
|---------------|----------------------|------------------------|
| GW3600-EH     | 3600W                | 230/220V               |
| GW5000-EH     | 5000W                |                        |
| GW6000-EH     | 6000W                |                        |
| GW3600N-EH    | 3600W                |                        |
| GW5000N-EH    | 5000W                |                        |
| GW5000N-EH-BE | 5000W                | 230V                   |
| GW5000-EH-BE  | 5000W                | 230V                   |
| GW6000N-EH    | 6000W                | 230/220V               |

## 1.2 Target Audience

This manual applies to trained and knowledgeable technical professionals. The technical personnel has to be familiar with the product, local standards, and electric systems.

## 1.3 Symbol Definition

Different levels of warning messages in this manual are defined as follows:

|  |
|--|
|  <b>DANGER</b>                |
| Indicates a high-level hazard that, if not avoided, will result in death or serious injury.                      |
|  <b>WARNING</b>               |
| Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.                   |
|  <b>CAUTION</b>               |
| Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.                     |
| <b>NOTICE</b>  |
| Highlights and supplements the texts. Or some skills and methods to solve product-related problems to save time. |

## 2 Safety Precaution

Please strictly follow these safety instructions in the user manual during the operation.



### WARNING

The inverters are designed and tested strictly in compliance with related safety rules. Read and follow all the safety instructions and cautions before any operations. Improper operation might cause personal injury or property damage as the inverters are electrical equipment.

### 2.1 General Safety

#### NOTICE

- The information in this user manual is subject to change due to product updates or other reasons. This guide cannot replace the product warning labels unless otherwise specified. All descriptions here are for guidance only.
- Before installations, read through the user manual to learn about the product and the precautions.
- All operations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Use insulating tools and wear personal protective equipment when operating the equipment to ensure personal safety. Wear anti-static gloves, clothes, and wrist strips when touching electron devices to protect the inverter from damage.
- Strictly follow the installation, operation, and configuration instructions in this manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions. For more warranty details, please visit <https://en.goodwe.com/warranty>.

### 2.2 PV String Safety



#### DANGER

Connect the DC cables of the inverter to the delivered DC terminals. Severe damage might happen if other types of DC terminals are used, which are beyond the manufacturer's liability.



#### WARNING

- Ensure the component frames and the bracket system are securely grounded.
- Ensure the DC cables are connected tightly, securely and correctly.
- Measure the DC cables with a multimeter to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one PV string to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.









### 2.3 Inverter Safety

 **WARNING**

- The voltage and frequency at the connection point meet the inverter grid connection requirements.
- Additional protective devices like circuit breakers or fuses are recommended on the AC side. Specification of the protective device should be at least 1.25 times the maximum AC output current.
- Make sure that all the groundings are tightly connected. When there are multiple inverters, make sure that all the grounding points on the enclosures are equipotential bonding.
- BACK-UP is not recommended if the PV system is not configured with batteries. Otherwise, the risk in system power usage is beyond the equipment manufacturer's warranty scope.
- Testing to AS/NZS 4777.2:2020 to multiple inverter combinations has not been conducted.

 **DANGER**

- All labels and warning marks should be visible after the installation. Do not cover, scrawl, or damage any label on the equipment.
- Warning labels on the inverter are as follows:

|   |  |   |  |
|---|--|---|--|
|    | DANGER High voltage hazard. Disconnect all incoming power and turn off the product before working on it. |    | Delayed discharge. Wait 5 minutes after power off until the components are completely discharged.  |
|    | Read through the user manual before any operations.  |    | Potential risks exist. Wear proper PPE before any operations.  |
|   | High-temperature hazard. Do not touch the product under operation to avoid being burnt.                  |   | Grounding point.   |
|  | CE certification mark  |  | Do not dispose of the inverter as household waste. Discard the product in compliance with local laws and regulations, or send it back to the manufacturer. |

## 2.4 Battery Safety

### WARNING

- The battery used with the inverter shall be approved by the inverter manufacturer. The approved battery list can be obtained through the official website.
- Before installations, read through the corresponding battery's User Manual to learn about the product and the precautions. Strictly follow its requirements.
- If the battery discharged completely, please charge it in strict accordance with the corresponding user manual.
- Factors such as: temperature, humidity, weather conditions, etc. may limit the battery's current and affect its load.
- Contact after-sale service immediately if the battery is not able to be started. Otherwise, the battery might be damaged permanently.
- Use the multimeter to measure the DC cable to avoid reverse polarity connection. Also, the voltage should be under the permissible range.
- Do not connect one battery group to several inverters at the same time. Otherwise, it may cause damage to the inverter.

## 2.5 Personal Requirements

### NOTICE

- Personnel who install or maintain the equipment must be strictly trained, learn about safety precautions and correct operations.
- Only qualified professionals or trained personnel are allowed to install, operate, maintain, and replace the equipment or parts.

## 2.6 EU Declaration of Conformity

GoodWe Technologies Co., Ltd. hereby declares that the inverter with wireless communication modules sold in the European market meets the requirements of the following directives:

- Radio Equipment Directive 2014/53/EU (RED)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

GoodWe Technologies Co., Ltd. hereby declares that the inverter without wireless communication modules sold in the European market meets the requirements of the following directives:

- Electromagnetic compatibility Directive 2014/30/EU (EMC)
- Electrical Apparatus Low Voltage Directive 2014/35/EU (LVD)
- Restrictions of Hazardous Substances Directive 2011/65/EU and (EU) 2015/863 (RoHS)
- Waste Electrical and Electronic Equipment 2012/19/EU
- Registration, Evaluation, Authorization and Restriction of Chemicals (EC) No 1907/2006 (REACH)

You can download the EU Declaration of Conformity on <https://en.goodwe.com>.



## 3 Product Introduction

### 3.1 Product Introduction

#### Intended usage

Inverters control and optimize the power in PV systems through an integrated energy management system. The power generated in the PV system can be used, stored in the battery, output to the utility grid, etc.

#### Model

This manual applies to the listed inverters below:

- GW3600-EH
- GW5000-EH
- GW5000-EH-BE
- GW6000-EH
- GW3600N-EH
- GW5000N-EH
- GW5000N-EH-BE
- GW6000N-EH


#### Model description

#### GW3000N-EH

1 2 3 4

| No. | Referring to    | Explanation                      |
|-----|-----------------|----------------------------------|
| 1   | Brand Code      | GW: GoodWe                       |
| 2   | Rated Power     | 3000: the rated power is 3000W.  |
| 3   | Product Feature | N: higher PV input current       |
| 4   | Series Code     | EH: single-phase hybrid inverter |

#### Supported Grid Types




## 3.2 Application Scenarios



### WARNING

- The PV system is not suitable to connect equipment that relies on a stable power supply, such as medical equipment to sustain life. Ensure that no personal injury is occurred when the system is disconnected.
- Avoid loads with high starting current like high-power water pumps in the PV system. Otherwise, the off-grid output may fail due to excessive instantaneous power.
- BACK-UP is not recommended if the PV system is not configured with batteries. Otherwise, the risk in system power usage is beyond the equipment manufacturer's warranty scope.
- Do not connect auto-coupling or isolation transformers to the BACK-UP port. Otherwise, the inverter may be damaged and the system power may fail.
- Factors such as: temperature, humidity, weather conditions, etc. may limit the battery's current and affect its load.
- The inverter offers UPS function. Under normal circumstances, the back up switching time is less than 10 ms.
- When single overload protection occurs, the inverter can restart automatically; however, the restarting time will be extended if it happens several times. For a faster restarting, try it via APP .
- When the grid is disconnected, the off-grid function of the inverter will be closed automatically if the load capacity exceeds the inverter's rated power; to enable it, turn off the large loads and ensure the load power is less than the rated power of the inverter.
- Normal household loads can be supported when the inverter is in back-up mode. Accepted loads as below:
  - Inductive loads: 1.5P non-inverter air conditioner can be connected to the inverter. If two or more non-inverter air conditioners are connected, the UPS may be unstable.
  - Capacitive load: total power  $\leq 0.6$  times of the inverter's rated output power.

## Self consumption mode



| No. | Parts                | Description   |
|-----|----------------------|---|
| 1   | PV String            | The PV string consists of PV modules.   |
| 2   | Inverter             | Support EH series and EH Plus series inverters.   |
| 3   | Battery              | Select the battery model according to the inverter model and the approved battery list.   |
| 4   | Battery breaker      | Recommended specifications: nominal current $\geq$ 40A, nominal voltage $\geq$ 600V.  |
| 5   | ON-GRID load breaker | Depend on the actual using load.  |
| 6   | ON-GRID breaker      | Self-prepared breaker. Recommended specifications: <ul style="list-style-type: none"> <li>GW3600N-EH, GW5000-EH, GW5000N-EH: nominal current<math>\geq</math>50A, nominal voltage<math>\geq</math>230V.</li> <li>GW6000-EH, GW6000N-EH: nominal current<math>\geq</math>63A, nominal voltage<math>\geq</math>230V.</li> </ul> |
| 7   | Smart meter          | Purchase the smart meter from the inverter manufacturer. Recommended model: GM1000.   |
| 8   | BACK-UP loads        | Connecting BACK-UP loads, such as loads requiring 24-hour power supply or other important loads.  |

| No. | Parts                | Description   |
|-----|----------------------|---|
| 9   | BACK-UP load breaker | Self-prepared breaker. Recommended specifications: <ul style="list-style-type: none"><li>• GW3600N-EH, GW5000-EH, GW5000N-EH: nominal current<math>\geq</math>50A, nominal voltage<math>\geq</math>230V.</li><li>• GW6000-EH, GW6000N-EH: nominal current<math>\geq</math>63A, nominal voltage<math>\geq</math>230V.</li></ul>  |
| 10  | Bypass switch        | To ensure the BACK-UP load is powered by the grid during the inverter maintenance, install a bypass switch by yourself. Recommended specifications: <ul style="list-style-type: none"><li>• GW3600N-EH, GW5000-EH, GW5000N-EH: nominal current<math>\geq</math>50A, nominal voltage<math>\geq</math>230V.</li><li>• GW6000-EH, GW6000N-EH: nominal current<math>\geq</math>63A, nominal voltage<math>\geq</math>230V.</li></ul> |

## 3.3 Working Mode


### 3.3.1 System Working Mode

#### Economic mode

#### NOTICE

- Select Economic mode only when it meets the local laws and regulations, e.g., whether the grid is allowed to charge the battery. If not, do not use this mode.
- It is recommended to use economic mode in scenarios when the peak-valley electricity price varies a lot.

- Daytime: when the electricity price is at its peak, the battery will power the load first, and the remaining power can be sold to the grid.
- Night: when the electricity price is at its valley, set the time for the grid to charge the battery.





### Self consumption mode

#### NOTICE

- For solar power, consider self consumption mode in priority: the excess power charges the battery in day time; the battery supplies power to the load when there is no solar power generated at night. This will improve the self consumption rate and saves electricity costs.
- It is suitable for areas with high electricity prices and little or no solar power generation subsidies.



- Day:
  - When the power generated in the PV system is sufficient, it will supply the loads in priority. And the excess power will charge the batteries first. The remaining power will be sold to the grid.
  - When the power generated in the PV system is insufficient or no power is generated, the battery will supply the loads in priority. If the battery power is insufficient, then the load will be powered by the grid.
- Night:  
If the battery power is sufficient, the load will be powered by the battery. If the battery power is not enough, the load will be powered by the grid.




## Back-up mode

### NOTICE

- The back-up mode is mainly applied to the scenario where the grid is unstable and there is an important load. When the grid is disconnected, the inverter turns to off-grid mode to supply power to the load; when the grid is restored, the inverter switches to on-grid mode.
- The battery stops discharging when it reaches SOC. When there is sunlight the next day, the battery starts to supply power to the load after it is charged to a certain power level.
- When the power generated in the PV system is sufficient, the power generated in the PV system will charge the battery in priority. And the excess power will charge the load. The remaining power will be sold to the grid.
- When there is no power generated in the PV system:
  - The grid will supply the load when it is normal. (Do not select this mode if the grid is not allowed to charge the battery according to the local laws and regulations.)
  - The inverter will enter off-grid mode and the battery will supply power to the load when the grid is abnormal.



### 3.3.3 Inverter Operation Mode



| No. | Parts           | Description   |
|-----|-----------------|---|
| 1   | Waiting mode    | Waiting stage after the inverter is powered on. <ul style="list-style-type: none"> <li>When the conditions are met, it enters the self-check mode.</li> <li>If there is a fault, the inverter enters the fault mode.</li> </ul>   |
| 2   | Self-check mode | Before the inverter starts up, it continuously performs self-check, initialization, etc. <ul style="list-style-type: none"> <li>When the conditions are met, it enters the grid-tied mode, and the inverter starts on grid connection.</li> <li>If the grid is not detected, it enters the off-grid mode and the inverter runs off-grid; if the inverter has no off-grid function, it enters the wait mode.</li> <li>If the self-check is not passed, it enters the fault mode.</li> </ul>                              |
| 3   | Grid-Tied mode  | The inverter is grid-tied successfully. <ul style="list-style-type: none"> <li>If the grid is not detected, it enters the off-grid mode.</li> <li>If a fault is detected, it enters the fault mode.</li> <li>If the conditions do not meet grid-tied requirements and the off-grid output function is not turned on, it enters the wait mode.</li> </ul>  |
| 4   | Off-grid mode   | When the grid is powered off, the inverter switches to the off-grid mode and continues to supply power to the load via BACK-UP port. <ul style="list-style-type: none"> <li>If a fault is detected, it enters the fault mode.</li> <li>If the conditions do not meet grid-tied requirements and the off-grid output function is not turned on, it enters the wait mode.</li> <li>If the conditions meet grid-tied requirements and the off-grid output function is turned on, it enters the self-check mode.</li> </ul> |
| 5   | Fault mode      | If a fault is detected, the inverter enters the fault mode. When the fault is cleared, it enters the wait mode.   |



## 3.4 Features

### Power Derating

For a safe operation, the inverter will automatically reduce the output power when the operating environment is not ideal.

The following are the factors that may occur power derating. Please try to avoid them when the inverter is working.

- Unfavorable environmental conditions, e.g., direct sunlight, high temperature, etc.
- Inverter's output power percentage has been set.
- Over-frequency derating.
- Higher input voltage value.
- Higher input current value.


### Earth Fault Alarm

Reserved port for earth fault alarm.

Once an earth fault occurs, the LED indicator will light up. And the system will email the fault information to the customer. Install the inverter in a high traffic area where the indicators would be noticed.

### 3.5 Appearance


#### 3.5.1 Parts
































- |  |                                |                                     |
|--|--------------------------------|-------------------------------------|
| 1. DC switch <sup>[1]</sup>                | 2. PV input terminal (PV1/PV2) | 3. Battery input terminal (BAT +/-) |
| 4. Communication module port (WiFi or LAN) | 5. BMS communication port      | 6. Meter communication port         |
| 7. Back-Up port                            | 8. On-Grid port                | 9. DRED communication port          |
| 10. RS485 communication port               | 11. Wi-Fi reset                | 12. Indicators                      |
| 13. PE terminal                            | 14. Heat sink                  | 15. Mounting Plate                  |

If the inverter is not equipped with a DC switch, an external DC breaker shall be added. The external DC breaker shall be AU/NZ certified; Complied to AS60947.3:2018; Be classified as DC-PV 2; With ratings and properties suitable for the intended application conditions such as outdoor, exposed to sunshine, on non-combustible material surface.

#### 3.5.2 Dimension




### 3.5.3 Indicators

| Indicators | Status  | Description   |
|------------|---|---|
| SYSTEM     |    | ON = The system is ready.                                     |
|            |    | BLINK = The system is starting.                               |
|            |    | OFF =The system is not working.                               |
| BACK-UP    |    | ON = Back-up is ready / power available.                      |
|            |    | OFF = Back-up is off / power not available.                   |
| BATTERY    |    | ON = The battery is charging.                                 |
|            |    | BLINK 1 = The battery is discharging.                         |
|            |    | BLINK 2 = The battery is low / soc is low.                    |
|            |    | OFF = The battery is disconnected / not active.               |
| GRID       |    | ON = The grid is active and connected.                        |
|            |    | BLINK = The grid is active but not connected.                 |
|            |    | OFF = The grid is not active.                                 |
| ENERGY     |    | ON = Consuming energy from grid / buying.                     |
|            |    | BLINK 1 = Supplying energy to grid / zeroing.                 |
|            |    | BLINK 2 = Supplying energy to grid / selling.                 |
|            |    | OFF = The grid is not connected or the system is not working. |
| COM        |    | ON = Both BMS communication and meter communication are ok.   |
|            |    | BLINK 1 = BMS communication fails; meter communication is ok. |
|            |   | BLINK 2 = BMS communication is ok; meter communication fails. |
|            |  | OFF = BMS communication and meter communication fail.         |
| WiFi       |  | ON = WiFi connected / active.                                 |
|            |  | BLINK 1 = WiFi is resetting.                                  |
|            |  | BLINK 2 = WiFi is not connected to the router.                |
|            |  | BLINK 4 = WiFi server problem.                                |
|            |  | OFF = WiFi is not active.                                     |
| FAULT      |  | ON = A fault has occurred.                                    |
|            |  | BLINK 1 = Back-up output overload / reduce load.              |
|            |  | BLINK 4 = Abnormal meter test result.                         |
|            |  | OFF = No fault.   |

### 3.5.4 Nameplate

The nameplate is for reference only.

|  |                            |   |
|--|----------------------------|---|
| <b>GOODWE</b>  |                            | GW trademark, product type, and product model |
| Product: Hybrid Inverter<br>Model: ***   |                            |   |
| PV Input   | UDC max: ***Vd.c.          | Technical parameters                          |
|  | UMPP: ***Vd.c.             |   |
|  | Idc,max: ***Ad.c.          |   |
|  | ISC PV: ***Ad.c.           |   |
| Battery  | Ubatt: ***Vd.c.,Li-Ion     |   |
|  | Ibatt,max(C/D): ***Ad.c    |   |
| On-grid  | UAC: ***Va.c.              |   |
|  | fAC: ***Hz                 |   |
|  | PAC: ***kW                 |   |
|  | IAC,max(to grid): ***Aa.c. |   |
|  | Sr(to grid): ***kVA        |   |
|  | Smax(to grid): ***kVA      |   |
|  | IAC(from grid): ***Aa.c.   |   |
| Back-up  | Sr(from grid): ***kVA      |   |
|  | Smax(from grid): ***kVA    |   |
|  | UAC,r: ***Va.c.            |   |
|  | fAC,r: ***Hz               |   |
|  | IAC,max: ***Aa.c.          |   |
| Sr: ***kVA   |                            |   |
| Smax: ***kVA   |                            |   |
| P.F.: -1,0.8cap...0.8ind, TOperating: -35~60°C<br>Non-isolated, IP66, Protective Class I, OVC DCII/ACIII                     |                            |   |
|   |                            | Safety symbols and certification marks        |
| S/N:   |                            | Contact information and serial number         |
| Good We Technologies Co., Ltd.<br>E-mail: service@goodwe.com<br>No.90 Ziji n Rd., New District, Suzhou, 215011, China<br>S/N |                            |   |

## 4 Check and Storage

### 4.1 Check Before Receiving

Check the following items before receiving the product.

1. Check the outer packing box for damage, such as holes, cracks, deformation, and other signs of equipment damage. Do not unpack the contents from the box and contact the supplier as soon as possible if any damage is found.
2. Check the inverter model. If the inverter model is not what you requested, do not unpack the product and contact the supplier.
3. Check the deliverables for correct model, complete contents, and intact appearance. Contact the supplier as soon as possible if any damage is found.


### 4.2 Deliverables

**WARNING**

Connect the DC cables with the included terminals. The manufacturer shall not be liable for the damage if other terminals are used.

**NOTICE**

- The number of expansion bolts, PV connectors, battery connectors, and ON-GRID/BACK-UP AC unlock tool are various depending on different inverters. The actual accessories may differ.
- The smart meter will not be included for Battery-Ready models. Contact the manufacturer or dealer to purchase the smart meter if you need.



### 4.3 Storage

If the equipment is not to be installed or used immediately, please ensure that the storage environment meets the following requirements:





1. Do not unpack the outer package or throw the desiccant away.
2. Store the equipment in a clean place. Make sure the temperature and humidity are appropriate and no condensation.
3. The height and direction of the stacking inverters should follow the instructions on the packing box.
4. The inverters must be stacked with caution to prevent them from falling.
5. If the inverter has been long term stored, it should be checked by professionals before being put into use.


## 5 Installation

### 5.1 Installation Requirements

#### Installation Environment Requirements

1. Do not install the equipment in a place near flammable, explosive, or corrosive materials.
2. Do not install the equipment in a place that is easy to touch, especially within children's reach. High temperature exists when the equipment is working. Do not touch the surface to avoid burning.
3. Avoid the water pipes and cables buried in the wall when drilling holes.
4. Install the equipment in a sheltered place to avoid direct sunlight, rain, and snow. Build a sunshade if it is needed.
5. Install the equipment in a well-ventilated place to ensure good dissipation. Also, the installation space should be large enough for operations.
6. The equipment with a high ingress protection rating can be installed indoors or outdoors. The temperature and humidity at the installation site should be within the appropriate range.
7. Install the equipment at a height that is convenient for operation and maintenance, electrical connections, and checking indicators and labels.
8. The inverter shall be installed below the maximum operating elevation of 3000m.
9. Install the equipment away from high magnetic fields to avoid electromagnetic interference. If there is any radio or wireless communication equipment below 30MHz near the equipment, you have to:
  - Add a multi-turn winding ferrite core at the DC input line or AC output line of the inverter, or add a low-pass EMI filter.
  - Install the inverter at least 30m far away from the wireless equipment.






### Mounting Support Requirements

- The mounting support shall be nonflammable and fireproof.
- Install the equipment on a surface that is solid enough to bear the inverter weight.
- Do not install the product on the support with poor sound insulation to avoid the noise generated by the working product, which may annoy the residents nearby.

### Installation Angle Requirements























- Install the inverter vertically or at a maximum back tilt of 15 degrees.
- Do not install the inverter upside down, forward tilt, back forward tilt, or horizontally.





## Installation Tool Requirements

The following tools are recommended when installing the equipment. Use other auxiliary tools on site if necessary.

|   |   |  |  |   |
|---|---|--|--|---|
|    |    |   |   |   |
| Goggles   | Safety shoes  | Safety gloves  | Dust mask  | RJ45 crimping tool  |
|    |    |   |   |   |
| Diagonal pliers   | Wire stripper   | Hammer drill   | Heat gun   | Vacuum cleaner  |
|    |    |   |   |   |
| Marker  | Level   | Heat shrink tube   | Rubber hammer  | Torque wrench<br>⊕ M3/M5  |
|   |    |  |  |  |
| Multimeter  | Cable tie   | Adjustable wrench  | Hydraulic pliers   | PV connector tool   |
|  |  |  |  |   |
| Battery connector tool  | Socket wrench   |  |  |   |

## 5.2 Inverter Installation

### 5.2.1 Moving the Inverter



- Operations such as transportation, shipment, installation and so on shall in compliance with the laws and regulations of the country or region where the inverter is located.
- Move the inverter to the site before installation. Follow the instructions below to avoid personal injury or equipment damage.
  1. Consider the weight of the equipment before moving it. Assign enough personnel to move the equipment to avoid personal injury.
  2. Wear safety gloves to avoid personal injury.
  3. Keep balance to avoid falling down when moving the equipment.

### 5.2.2 Installing the Inverter

#### NOTICE

- Avoid the water pipes and cables buried in the wall when drilling holes.
- Wear goggles and a dust mask to prevent the dust from being inhaled or contacting eyes when drilling holes.
- Make sure the inverter is firmly installed in case of falling down.
- The DC switch lock is prepared by the customer.

**Step 1:** Put the plate on the wall horizontally and mark positions for drilling holes.

**Step 2:** Drill holes to a depth of 80mm using the hammer drill. The diameter of the drill bit should be 8mm.








**Step 3:** Use the expansion bolts to fix the inverter on the wall.

**Step 4: (Optional)** Secure the DC switch with the DC switch lock, ensuring that the DC switch is "OFF" during installation.

**Step 5:** Install the inverter on the mounting plate.

**Step 6:** Tighten the nuts to secure the mounting plate and the inverter.

**Step 7:** Install the anti-theft lock.



## 6 Electrical Connection

### 6.1 System Wiring Diagram


#### NOTICE

- N and PE wiring via ON-GRID and BACK-UP ports of the inverter are different based on the regulation requirements of different regions. Refer to the specific requirements of local regulations.
- There are integrated relays inside of the inverter's ON-GRID and BACK-UP AC ports. When the inverter is in the off-grid mode, the ON-GRID relay is disconnected; while when the inverter is in grid-tied mode, it is connected.
- When the inverter is powered on, the BACK-UP AC port is live. Power off the inverter first if maintenance is required for the loads connected to BACK-UP ports. Otherwise, it may cause electric shock.

**N and PE cables are connected together in the Main Panel for wiring.**

#### NOTICE


The following diagram is applicable to areas in Australia, New Zealand, etc.



**N and PE cables are separately wired in the Main Panel.**

**NOTICE**

The following diagram is applicable to areas except Australia and New Zealand.



## 6.2 Safety Precautions



- Perform electrical connections in compliance with local laws and regulations. Including operations, cables, and component specifications.
- Disconnect the DC switch and the AC output switch of the inverter to power off the inverter before any electrical connections. Do not work with power on. Otherwise, an electric shock may occur.
- Tie the cables of the same type together, and place cables of different types apart. Do not place the cables entangled or crossed.
- If there is too much tension on a wire, it may be poorly connected. Reserve the appropriate length of wire before connection.
- Make sure that the cable conductor is in full contact with the terminal and the cable insulation part is not crimped with the terminal when crimping the terminal. Otherwise, the inverter may not be able to work properly, or the connection may be unreliable during working, which may cause terminal block damage, etc.


### NOTICE

- Wear personal protective equipment like safety shoes, safety gloves, and insulating gloves during electrical connections.
- All electrical connections should be performed by qualified professionals.
- Cable colors in this document are for reference only. The cable specifications shall meet local laws and regulations.

## 6.3 Connecting the PE Cable



- The PE cable connected to the enclosure of the inverter cannot replace the PE cable connected to the AC output port. Make sure that both of the two PE cables are securely connected.
- Make sure that all the grounding points on the enclosures are equipotential connected when there are multiple inverters.
- To improve the corrosion resistance of the terminal, you are recommended to apply silica gel or paint on the ground terminal after installing the PE cable.
- The PE cable should be prepared by the customer. Recommended specifications:
  - Type: single-core outdoor copper cable
  - Conductor cross-sectional area: 4mm<sup>2</sup>




## 6.4 Connecting the DC Input Cable (PV)

### ⚠ DANGER

- Do not connect one PV string to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.
- Confirm the following information before connecting the PV string to the inverter. Otherwise, the inverter may be damaged permanently or even cause fire and cause personal and property losses.
  - Make sure that the max short circuit current and the max input voltage per MPPT are within the permissible range.
  - Make sure that the positive pole of the PV string connects to the PV+ of the inverter. And the negative pole of the PV string connects to the PV- of the inverter.

### ⚠ WARNING

The PV strings cannot be grounded. Ensure the minimum insulation resistance of the PV string to the ground meets the minimum insulation resistance requirements before connecting the PV string to the inverter ( $R=\text{maximum input voltage}/30\text{mA}$ ).



### Vaconn

**1**

7-8mm  
 $\Phi: 5.5-8\text{mm}$   
7-8mm  
 $2.5\text{mm}^2 \leq S \leq 4\text{mm}^2$

**2**

**3**

Click  
⚠️

**4**

**5**


$\leq 580\text{V}$  ✓

**6**

Click



# MC4



## 6.5 Connecting the Battery Cable

### NOTICE


- For Battery-Ready inverters, please contact the manufacturer or dealer to activate the battery related functions first if you need them. Do not connect any battery to the inverter if the battery related functions are not activated. Otherwise the inverter will stop working.
- Ensure that the battery ports are sealed properly if there is no battery connected.

### DANGER





- The battery used with the inverter shall be approved by the inverter manufacturer. The approved battery list can be obtained through the official website.
- A short circuit in the battery may cause personal injury. The instantaneous high current caused by a short circuit can release a large amount of energy and may cause a fire.
- Before connecting the battery cable, ensure the inverter and the battery, and downstream&upstream switches, are all disconnected.
- It is forbidden to connect and disconnect the battery cables when the inverter is running. Otherwise it may cause electric shock.
- Do not connect one battery pack to more than one inverter at the same time. Otherwise, it may cause damage to the inverter.
- It is forbidden to connect loads between the inverter and batteries.
- When connecting battery cables, use insulated tools to prevent accidental electric shock or short circuit to the batteries.
- Ensure that the open circuit voltage of the battery is within the permissible range of the inverter.

### WARNING

- Connect the battery cables to the corresponding terminals such BAT+, BAT- and grounding ports correctly. Otherwise it will cause damage to the inverter.
- Ensure that the whole cable cores are inserted into the terminal holes. No part of the cable core can be exposed.
- Ensure that the cables are connected securely. Otherwise it will cause damage to the inverter due to overheat during its operation.
- An external DC circuit breaker is recommended if there is no integrated DC circuit breaker inside the battery. Recommended specifications: 40A/600V.



## Phoenix



## 6.6 Connecting the AC Cable

### NOTICE

- Install one AC circuit breaker for each inverter. Multiple inverters cannot share one AC circuit breaker. Do not connect loads between the inverter and the AC switch directly connected to the inverter.
- An AC circuit breaker shall be installed on the AC side to make sure that the inverter can safely disconnect the grid when an exception happens. Select an appropriate AC circuit breaker in compliance with local laws and regulations.
- For AC cable, the PE conductor shall be longer than N&L conductors, so that once the AC cable slips or taken out, the protecting earth conductor will be the last to take the strain.
- Remove the AC protection cover based on actual situation.



### WARNING








- Connect the AC cables to the corresponding terminals such as “L”, “N”, and PE correctly. Otherwise it will cause damage to the inverter.
- Ensure that the whole cable cores are inserted into the terminal holes. No part of the cable core can be exposed.
- Ensure that the cables are connected securely. Otherwise it will cause damage to the inverter due to overheat during its operation.
- When there is no need to connect AC cables, the terminal cover should not be removed from the ON-GRID and Back-UP ports to ensure that the ports are protected and there is no risk of electric shock for personnel.




### WARNING

- Do not connect any AC generator to the ON-GRID or BACK-UP port.
- The Residual Current Monitoring Unit (RCMU) is integrated into the inverter. The inverter will disconnect the utility grid rapidly once it detects any leak current over the permissible range.
- There are integrated relays inside of the inverter's ON-GRID and BACK-UP AC ports. When the inverter is in the off-grid mode, the ON-GRID relay is disconnected; while when the inverter is in grid-tied mode, it is connected.
- When the inverter is powered on, the BACK-UP AC port is live. Power off the inverter first if maintenance is required for the loads connected with BACK-UP ports. Otherwise, it may cause electric shock.
- Connect a Residual Current Device (RCD for short) based on local laws and regulations. A type A RCD can be connected to the inverter for protection when DC component of the leakage exceeds the limit. Recommended RCD specifications:  $\geq 30\text{mA}$ .

### 6.6.1 Connecting the AC Cable (ON-GRID)








### 6.6.2 Connecting the AC Cable (BACK-UP)








**NOTICE**

- Ensure that the BACK-UP PE cable is connected properly and securely. Otherwise, the BACK-UP function may not work when the grid fails.
- Do not connect the utility grid or any other inverter to the BACK-UP port of the inverter.
- A double-pole three-throw switch (DP3T for short) is recommended to be added on the BACK-UP side for convenient maintenance.

**WARNING**

- The absence of an AC breaker on the BACK-Up side may lead to inverter damage once an electrical short-circuit happens. And the BACK-UP function cannot be turned off when the inverter is on grid.
- Recommended specification of the circuit breaker: 32A/230V.









## 6.7 Communication Connection


### 6.7.1 Connecting the Communication Cable

#### NOTICE

- Make sure that the communication device is connected to the right COM port. Route the communication cable far away from any interference source or power cable to prevent the signal from being influenced.
- DRED is only for Australia and New Zealand. Connect the DRED cable using a 6PIN communication terminal. The communication cable and third-party DRED device should be prepared by customers.
- Connect the remote shutdown cable using the 2PIN of a communication terminal. The communication cable should be prepared by customers.
- Remove the resistor and keep it properly for later use.









### 6.7.2 Connecting BMS or Meter Communication Cable (Optional)

#### NOTICE

- The smart meter and CT have been preset parameters before delivered with the inverter. Do not modify the relevant parameters.
- The BMS communication cable and communication cable between the inverter and the smart meter is included. For Battery-Ready inverters, the communication cable is not included and should be prepared by customers.
- One smart meter can be connected to one inverter. Do not connect one smart meter to multiple inverters. Contact the manufacturer or dealer to purchase additional smart meter(s) if you need.
- Ensure that CT connects with the corresponding phase line: CT1 is connected to L1; CT2 is connected to L2; and CT3 is connected to L3. And ensure that the CT is connected in the right direction. Please refer to the smart meter user manual for detailed operations.
- RJ45 connector with the following definition can be connected for BMS and meter communication:

| No. | Color        | BMS    | Smart meter | RS485 |
|-----|--------------|--------|-------------|-------|
| 1   | Orange&White | 485_A2 | NC          | 485_A |
| 2   | Orange       | NC     | NC          | 485_B |
| 3   | Green&White  | 485_B2 | 485_B1      | 485_A |
| 4   | Blue         | CAN_H  | NC          | NC    |
| 5   | Blue&White   | CAN_L  | NC          | NC    |
| 6   | Green        | NC     | 485_A1      | 485_B |
| 7   | Brown&White  | NC     | 485_B1      | NC    |
| 8   | Brown        | NC     | 485_A1      | NC    |






**NOTICE**

Power limit can be realized when the inverter is installed with a smart meter. The specific networkings are as follows.


**Single phase scenario**

When single phase loads are connected, the power limit can be realized by connecting EH or EH Plus series inverters with GM1000.



## Split phase scenario

When split phase loads are connected, the power limit can be realized by connecting EH or EH Plus series inverters with GM3000.




### 6.7.3 Installing the Communication Module (Optional)

Plug a WiFi Kit or Wi-Fi/LAN Kit module into the inverter to establish a connection between the inverter and the smartphone or web pages, which allows set inverter parameters, check running information and fault information, and observe system status in time.

#### NOTICE

Refer to the delivered communication module user manual to get more introduction to the module. For more detailed information, visit [www.goodwe.com](http://www.goodwe.com).



#### WiFi Reset or Reload

Short press the reset button. The WiFi indicator will blink until the WiFi module is reset.

Long press the reset button more than 3s. The WiFi indicator will double blink until the WiFi is configured again.

Reset or Reload the WiFi module when:

1. Cannot connect to SolarGo app
2. Cannot find "Solar-WiFi signal"
3. WiFi connection failure etc.

## 7 Equipment Commissioning

### 7.1 Check Before Power ON

| No. | Check Item  |
|-----|---|
| 1   | The product is firmly installed at a clean place that is well-ventilated and easy-to operate.     |
| 2   | The PE, DC input, AC output, and communication cables are connected correctly and securely.       |
| 3   | Cable ties are intact, routed properly and evenly.  |
| 4   | Unused cable holes are fitted using the waterproof nuts.  |
| 5   | The voltage and frequency at the connection point meet the inverter grid connection requirements. |

### 7.2 Power On

**Step 1:** Turn on the AC breaker on the ON-GRID side of the inverter.






























**Step 2:** Turn on the AC breaker on the BACK-UP side of the inverter.

**Step 3:** Turn on the battery breaker between the inverter and the battery.

**Step 4:** Turn on the DC switch of the inverter.

## 8 System Commissioning

### 8.1 Indicators and Buttons

| Indicators | Status  | Description   |
|------------|---|---|
| SYSTEM     |    | ON = The system is ready.                                     |
|            |    | BLINK = The system is starting.                               |
|            |    | OFF =The system is not working.                               |
| BACK-UP    |    | ON = Back-up is ready / power available.                      |
|            |    | OFF = Back-up is off / power not available.                   |
| BATTERY    |    | ON = The battery is charging.                                 |
|            |    | BLINK 1 = The battery is discharging.                         |
|            |    | BLINK 2 = The battery is low / soc is low.                    |
|            |    | OFF = The battery is disconnected / not active.               |
| GRID       |    | ON = The grid is active and connected.                        |
|            |    | BLINK = The grid is active but not connected.                 |
|            |    | OFF = The grid is not active.                                 |
| ENERGY     |    | ON = Consuming energy from grid / buying.                     |
|            |    | BLINK 1 = Supplying energy to grid / zeroing.                 |
|            |    | BLINK 2 = Supplying energy to grid / selling.                 |
|            |    | OFF = The grid is not connected or the system is not working. |
| COM        |    | ON = Both BMS communication and meter communication are ok.   |
|            |    | BLINK 1 = BMS communication fails; meter communication is ok. |
|            |  | BLINK 2 = BMS communication is ok; meter communication fails. |
|            |  | OFF = BMS communication and meter communication fail.         |
| WiFi       |  | ON = WiFi connected / active.                                 |
|            |  | BLINK 1 = WiFi is resetting.                                  |
|            |  | BLINK 2 = WiFi is not connected to the router.                |
|            |  | BLINK 4 = WiFi server problem.                                |
|            |  | OFF = WiFi is not active.                                     |
| FAULT      |  | ON = A fault has occurred.                                    |
|            |  | BLINK 1 = Back-up output overload / reduce load.              |
|            |  | BLINK 4 = Abnormal meter test result.                         |
|            |  | OFF = No fault.   |

## 8.2 Setting Inverter Parameters via SolarGo App

### NOTICE

Please set the inverter parameters first via SolarGo app to ensure its normal operation.

SolarGo App is one smart phone application used to communicate with the inverter via bluetooth, WiFi, 4G or GPRS modules. Commonly used functions:

1. Check the operating data, software version, alarms, etc.
2. Set grid parameters, communication parameters, safety countries, power limitation, etc.
3. Equipment maintenance.
4. Upgrade software version.

For more details, refer to SolarGo User Manual. Scan the QR code or visit [https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW\\_SolarGo\\_User%20Manual-EN.pdf](https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SolarGo_User%20Manual-EN.pdf) to get the user manual.



SolarGo App



SolarGo User Manual

### NOTICE

For Australian customers please select from Australia Region A/B/C to comply with AS/NZS 4777.2:2020. Contact local grid operator to see which Region to select. After setting the safety region, some parameters in the inverter system will take effect according to the corresponding safety regulations, such as PU curve, QU curve, trip protection, etc. For Australian and European users, if you need to change the configuration parameters, please refer to the SolarGo user manual.

## 8.3 Monitoring via SEMS Portal

SEMS Portal is a monitoring platform used to communicate with the inverter via WiFi, LAN, 4G, or GPRS. Commonly used functions:

1. Manage the organization or User information;
2. Add and monitor the power plant information;
3. Equipment maintenance.

For more details, refer to SEMS Portal User Manual. Scan the QR code or visit [https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW\\_SEMS%20Portal%20APP\\_User%20Manual-EN.pdf](https://en.goodwe.com/Ftp/EN/Downloads/User%20Manual/GW_SEMS%20Portal%20APP_User%20Manual-EN.pdf) to get the user manual.



SEMS Portal App



SEMS Portal app User Manual

## 9 Maintenance

### 9.1 Power OFF the Inverter

#### DANGER

- Power off the inverter before operations and maintenance. Otherwise, the inverter may be damaged or electric shocks may occur.
- Delayed discharge. Wait until the components are discharged after power off.

**Step 1:** Turn off the AC breaker on the ON-GRID side of the inverter.

**Step 2:** Turn off the AC breaker on the BACK-UP side of the inverter.

**Step 3:** Turn off the battery breaker between the inverter and the battery.

**Step 4:** Turn off the DC switch of the inverter.



### 9.2 Removing the Inverter


#### WARNING

- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.



**Step 1:** Disconnect all the cables, including DC cables, AC cables, communication cables, the communication module, and PE cables.

#### Remove the ON-GRID connector





**Remove the BACK-UP connector**



**Step 2:** Remove the inverter from the mounting plate.

**Step 3:** Remove the mounting plate.

**Step 4:** Store the inverter properly. If the inverter needs to be used later, ensure that the storage conditions meet the requirements.

### 9.3 Disposing of the Inverter

If the inverter cannot work anymore, dispose of it according to the local disposal requirements for electrical equipment waste. The inverter cannot be disposed of together with household waste.



## 9.4 Troubleshooting

Perform troubleshooting according to the following methods. Contact the after-sales service if these methods do not work.

Collect the information below before contacting the after-sales service, so that the problems can be solved quickly.

1. Inverter information like serial number, software version, installation date, fault time, fault frequency, etc.
2. Installation environment, including weather conditions, whether the PV modules are sheltered or shadowed, etc. It is recommended to provide some photos and videos to assist in analyzing the problem.
3. Utility grid situation.

| No. | Fault            | Cause  | Solutions  |
|-----|------------------|--|--|
| 1   | Utility Loss     | 1. Utility grid power fails.<br>2. The AC cable is disconnected, or the AC breaker is off.                       | 1. The alarm is automatically cleared after the grid power supply is restored.<br>2. Check whether the AC cable is connected and the AC breaker is on.   |
| 2   | Grid Overvoltage | The grid voltage exceeds the permissible range, or the duration of high voltage exceeds the requirement of HVRT. | 1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.<br>2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> <li>• Contact the local power company if the grid voltage exceeds the permissible range.</li> <li>• Modify the overvoltage protection threshold, HVRT or disable the overvoltage protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range.</li> </ul> 3. Check whether the AC breaker and the output cables are connected securely and correctly if the problem persists. |

| No. | Fault                  | Cause   | Solutions  |
|-----|------------------------|---|--|
| 3   | Grid Rapid Overvoltage | The grid voltage is abnormal or ultra-high.   | <ol style="list-style-type: none"> <li>1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> <li>• Contact the local power company if the grid voltage exceeds the permissible range.</li> <li>• Modify the grid overvoltage rapid protection threshold after obtaining the consent of the local power company if the grid voltage is within the permissible range.</li> </ul> </li> </ol>  |
| 4   | Grid Undervoltage      | The grid voltage is lower than the permissible range, or the duration of low voltage exceeds the requirement of LVRT. | <ol style="list-style-type: none"> <li>1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> <li>• Contact the local power company if the grid voltage exceeds the permissible range.</li> <li>• Modify the undervoltage protection threshold, LVRT or disable the undervoltage protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range.</li> </ul> </li> <li>3. Check whether the AC breaker and the output cables are connected securely and correctly if the problem persists.</li> </ol> |
| 5   | Grid 10min Overvoltage | The moving average of grid voltage in 10min exceeds the range of safety requirements.                                 | <ol style="list-style-type: none"> <li>1. If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>2. If the problem occurs frequently, check whether the grid voltage is within the permissible range. <ul style="list-style-type: none"> <li>• Contact the local power company if the grid voltage exceeds the permissible range.</li> <li>• Modify the grid overvoltage rapid protection threshold after obtaining the consent of the local power company if the grid voltage is within the permissible range.</li> </ul> </li> </ol>  |

| No. | Fault               | Cause  | Solutions   |
|-----|---------------------|--|---|
| 6   | Grid Overfrequency  | Utility grid exception. The actual grid frequency exceeds the requirement of the local grid standard.  | <ol style="list-style-type: none"> <li>If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>If the problem occurs frequently, check whether the grid frequency is within the permissible range. <ul style="list-style-type: none"> <li>Contact the local power company if the grid frequency exceeds the permissible range.</li> <li>Modify the overfrequency protection threshold or disable the overfrequency protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range.</li> </ul> </li> </ol>   |
| 7   | Anti-islanding      | The utility grid is disconnected. The utility grid is disconnected according to the safety regulations, but the grid voltage is maintained due to the loads. | <ol style="list-style-type: none"> <li>Check whether the utility grid is disconnected.</li> <li>Contact the dealer or the after-sales service.</li> </ol>   |
| 8   | Grid Underfrequency | Utility grid exception. The actual grid frequency is lower than the requirement of the local grid standard.  | <ol style="list-style-type: none"> <li>If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>If the problem occurs frequently, check whether the grid frequency is within the permissible range. <ul style="list-style-type: none"> <li>Contact the local power company if the grid frequency exceeds the permissible range.</li> <li>Modify the underfrequency protection threshold or disable the underfrequency protection function after obtaining the consent of the local power company if the grid frequency is within the permissible range.</li> </ul> </li> </ol> |

| No. | Fault                      | Cause   | Solutions   |
|-----|----------------------------|---|---|
| 9   | Grid Frequency Instability | Utility grid exception. The actual grid frequency change rate does not meet the requirement of the local grid standard. | <ol style="list-style-type: none"> <li>If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>If the problem occurs frequently, check whether the grid frequency is within the permissible range.                             <ul style="list-style-type: none"> <li>Contact the local power company if the grid frequency exceeds the permissible range.</li> <li>Contact the dealer or the after-sales service if the grid frequency is within the permissible range.</li> </ul> </li> </ol> |
| 10  | LVRT Undervoltage          | Utility grid exception. The duration of the utility grid exception exceeds the set time of LVRT.                        | <ol style="list-style-type: none"> <li>If the problem occurs occasionally, the utility grid may be abnormal temporarily. The inverter will recover automatically after detecting that the utility grid is normal.</li> <li>If the problem occurs frequently, check whether the grid frequency is within the permissible range. If not, contact the local power company. If yes, contact the dealer or the after-sales service.</li> </ol>   |
| 11  | HVRT Overvoltage           | Utility grid exception. The duration of utility grid exception exceeds the set time of HVRT.                            |   |
| 12  | Abnormal GFCI 30mA         | The input insulation impedance becomes low when the inverter is working.  |   |
| 13  | Abnormal GFCI 60mA         |   |   |
| 14  | Abnormal GFCI 150mA        |   |   |
| 15  | Abnormal GFCI              |   |   |
| 16  | Large DC of AC current L1  | The DC component of the output current exceeds the safety range or default range.                                       | <ol style="list-style-type: none"> <li>If the problem is caused by an external fault like a utility grid exception or frequency exception, the inverter will recover automatically after solving the problem.</li> <li>If the problem occurs frequently and the PV station cannot work properly, contact the dealer or the after-sales service.</li> </ol>  |
| 17  | Large DC of AC current L2  |   |   |

| No. | Fault                      | Cause  | Solutions   |
|-----|----------------------------|--|---|
| 18  | Low Insulation Res.        | <ol style="list-style-type: none"> <li>The PV string is short-circuited to PE.</li> <li>The PV system is in a moist environment and the cable is not well insulated to the ground.</li> </ol>  | <ol style="list-style-type: none"> <li>Check whether the resistance of the PV string to PE exceeds 50kΩ. If no, check the short circuit point.</li> <li>Check whether the PE cable is connected correctly.</li> <li>If the resistance is lower on rainy days, please reset the ISO.</li> </ol>          |
| 19  | Abnormal Ground            | <ol style="list-style-type: none"> <li>The PE cable of the inverter is not connected well.</li> <li>The L cable and N cable are connected reversely when output of the PV string is grounded.</li> </ol>   | <ol style="list-style-type: none"> <li>Check whether the PE cable of the inverter is connected properly.</li> <li>Check whether the L cable and N cable are connected reversely if output of the PV string is grounded.</li> </ol>  |
| 20  | Anti Reverse power Failure | Abnormal fluctuation of load   | <ol style="list-style-type: none"> <li>If the exception is caused by an external fault, the inverter will recover automatically after solving the problem.</li> <li>If the problem occurs frequently and the PV station cannot work properly, contact the dealer or the after-sales service.</li> </ol> |
| 21  | Internal Comm Loss         | <ol style="list-style-type: none"> <li>Frame format error</li> <li>Parity checking error</li> <li>Can bus offline</li> <li>Hardware CRC error</li> <li>Send (receive) control bit is receive (send).</li> <li>Transmit to the unit that is not allowed.</li> </ol> | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.</p>   |
| 22  | AC HCT Check abnormal      | The sampling of the AC HCT is abnormal.  | <p>Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.</p>   |

| No. | Fault                   | Cause  | Solutions  |
|-----|-------------------------|--|--|
| 23  | GFCI HCT Check abnormal | The sampling of the GFCI HCT is abnormal.  | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.   |
| 24  | Relay Check abnormal    | <ol style="list-style-type: none"> <li>1. The relay is abnormal or short-circuited.</li> <li>2. The control circuit is abnormal.</li> <li>3. The AC cable connection is abnormal, like a virtual connection or short circuit.</li> </ol> | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.   |
| 26  | Flash Fault             | The internal Flash storage is abnormal.  | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.   |
| 27  | DC Arc Fault            | <ol style="list-style-type: none"> <li>1. The DC terminal is not firmly connected.</li> <li>2. The DC cable is broken.</li> </ol>  | Read the Quick Installation Guide and check whether the cables are connected properly.   |
| 28  | AFCI Self-test Fault    | AFCI detection is abnormal.  | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.   |
| 29  | Cavity Overtemperature  | <ol style="list-style-type: none"> <li>1. The inverter is installed in a place with poor ventilation.</li> <li>2. The ambient temperature exceeds 60°C.</li> <li>3. A fault occurs in the internal fan of the inverter.</li> </ol>       | <ol style="list-style-type: none"> <li>1. Check the ventilation and the ambient temperature at the installation point.</li> <li>2. If the ventilation is poor or the ambient temperature is too high, improve the ventilation and heat dissipation.</li> <li>3. Contact the dealer or after-sales service if both the ventilation and the ambient temperature are normal.</li> </ol> |
| 30  | BUS Overvoltage         | <ol style="list-style-type: none"> <li>1. The PV voltage is too high.</li> <li>2. The sampling of the inverter BUS voltage is abnormal.</li> </ol>   | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.   |

| No. | Fault                              | Cause   | Solutions   |
|-----|------------------------------------|---|---|
| 31  | PV Input Overvoltage               | The PV array configuration is not correct. Too many PV panels are connected in series in the PV string.                       | Check the serial connection of the PV array. Make sure that the open circuit voltage of the PV string is not higher than the maximum operating voltage of the inverter. |
| 32  | PV Continuous Hardware Overcurrent | <ol style="list-style-type: none"> <li>1. The PV configuration is not proper.</li> <li>2. The hardware is damaged.</li> </ol> | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.          |
| 33  | PV Continuous Software Overcurrent | <ol style="list-style-type: none"> <li>1. The PV configuration is not proper.</li> <li>2. The hardware is damaged.</li> </ol> | Disconnect the AC output switch and DC input switch, then connect them 5 minutes later. Contact the dealer or the after-sales service if the problem persists.          |
| 34  | String1 PV String Reversed         | The PV string is connected reversely.   | Check whether the PV strings are connected reversely.   |
| 35  | String2 PV String Reversed         |   |   |

## 9.5 Routine Maintenance



**WARNING**

- Make sure that the inverter is powered off.
- Wear proper PPE before any operations.

| Maintaining Item      | Maintaining Method  | Maintaining Period |
|-----------------------|---|--------------------|
| System Clean          | Check the heat sink, air intake, and air outlet for foreign matter or dust.   | Once 6-12 months   |
| DC Switch             | Turn the DC switch on and off ten consecutive times to make sure that it is working properly.   | Once a year        |
| Electrical Connection | Check whether the cables are securely connected. Check whether the cables are broken or whether there is any exposed copper core.   | Once 6-12 months   |
| Sealing               | Check whether all the terminals and ports are properly sealed. Reseal the cable hole if it is not sealed or too big.  | Once a year        |
| THDi Test             | For Australia requirements, in the THDi test, there should add Zref between inverter and mains.<br>L: $0.24 \Omega + j0.15 \Omega$ ; N: $0.16 \Omega + j0.10 \Omega$<br>L: $0.15 \Omega + j0.15 \Omega$ ; N: $0.1 \Omega + j0.1 \Omega$ | As needed.         |



## 10 Technical Parameters

| Technical Data   | GW3600-EH | GW5000-EH | GW6000-EH |
|--|-----------|-----------|-----------|
| <b>Battery Input Data</b>  |           |           |           |
| Battery Type   | Li-Ion    |           |           |
| Nominal Battery Voltage (V)                                      | 350       |           |           |
| Battery Voltage Range (V)  | 85~460    |           |           |
| Max. Continuous Charging Current (A)                             | 25        |           |           |
| Max. Continuous Discharging Current (A)                          | 25        |           |           |
| Max. Charge Power (W)  | 3,600     | 5,000     | 6,000     |
| Max. Discharge Power (W)   | 3,600     | 5,000     | 6,000     |
| <b>PV String Input Data</b>                                      |           |           |           |
| Max. Input Power (W)   | 4,800     | 6,650     | 8,000     |
| Max. Input Voltage (V)   | 580       |           |           |
| MPPT Operating Voltage Range (V)                                 | 100~550   |           |           |
| MPPT Voltage Range at Nominal Power (V)                          | 150~550   | 210~550   | 250~550   |
| Start-up Voltage (V)   | 90        |           |           |
| Nominal Input Voltage (V)  | 380       |           |           |
| Max. Input Current per MPPT (A)                                  | 12.5      |           |           |
| Max. Short Circuit Current per MPPT (A)                          | 15.2      |           |           |
| Max. Backfeed Current to The Array (A)                           | 0         |           |           |
| Number of MPP Trackers   | 2         |           |           |
| Number of Strings per MPPT                                       | 1         |           |           |
| <b>AC Output Data (On-grid)</b>                                  |           |           |           |
| Nominal Apparent Power Output to Utility Grid (VA) <sup>*1</sup> | 3,600     | 5,000     | 6,000     |
| Max. Apparent Power Output to Utility Grid (VA) <sup>*1</sup>    | 3600      | 5000      | 6000      |

| Technical Data                                    | GW3600-EH                                  | GW5000-EH                              | GW6000-EH                                |
|---|--|--|--|
| Nominal Apparent Power from Utility Grid(VA)      | 7,200                                      | 10,000                                 | 12,000                                   |
| Max. Apparent Power from Utility Grid (VA)        | 7200(Charging 3.6kw, Backup Output 3.6kw)  | 10000(Charging 5kw, Backup Output 5kw) | 12,000 (Charging 6kW, Backup Output 6kW) |
| Nominal Output Voltage (V)                        | 230/220*5                                  |  |  |
| Output Voltage Range (V)                          | 0~300                                      |  |  |
| Nominal AC Grid Frequency (Hz)                    | 50/60                                      |  |  |
| AC Grid Frequency Range (Hz)                      | 45~65                                      |  |  |
| Max. AC Current Output to Utility Grid (A)        | 16   | 21.7                                   | 26.1/27.3*7                              |
| Max. AC Current From Utility Grid (A)             | 32.0                                       | 43.4                                   | 52.2                                     |
| Max. Output Fault Current (Peak and Duration) (A) | 65@5μs                                     |  |  |
| Inrush Current (Peak and Duration) (A)            | 65@5μs                                     |  |  |
| Nominal Output Current (A)                        | 15.6                                       | 21.7                                   | 26.1                                     |
| Power Factor                                      | Adjustable from 0.8 leading to 0.8 lagging |  |  |
| Max. Total Harmonic Distortion                    | <3%  |  |  |
| Maximum Output Overcurrent Protection (A)         | 40   | 54                                     | 65                                       |
| <b>AC Output Data (Back-up)</b>                   |  |  |  |
| Back-up Nominal Apparent Power (VA)               | 3,600                                      | 5,000                                  | 6,000                                    |
| Max. Output Apparent Power (VA)                   | 3,600 (4,320 @60sec)                       | 5,000 (6,000@60sec)                    | 6,000 (7,200@60sec)                      |
| Nominal Output Current (A)                        | 15.7                                       | 21.7                                   | 26.1                                     |
| Max. Output Current (A)                           | 15.7                                       | 21.7                                   | 26.1                                     |
| Max. Output Fault Current (Peak and Duration) (A) | 19@60s                                     | 26@60s                                 | 31@60s                                   |
| Inrush Current (Peak and Duration) (A)            | 65@5μs                                     | 65@5μs                                 | 65@5μs                                   |
| Maximum Output Overcurrent Protection (A)         | 16   | 21.7                                   | 26.1                                     |

| Technical Data                      | GW3600-EH                  | GW5000-EH | GW6000-EH |
|-------------------------------------|----------------------------|-----------|-----------|
| Nominal Output Voltage (V)          | 230 (±2%)                  |           |           |
| Nominal Output Frequency (Hz)       | 50/60 (±0.2%)              |           |           |
| Output THDv (@Linear Load)          | <3%                        |           |           |
| <b>Efficiency</b>                   |                            |           |           |
| Max. Efficiency                     | 97.6%                      |           |           |
| European Efficiency                 | 97.0%                      |           |           |
| Max. Battery to AC Efficiency       | 96.6%                      |           |           |
| MPPT Efficiency                     | 99.9%                      |           |           |
| <b>Protection</b>                   |                            |           |           |
| PV Insulation Resistance Detection  | Integrated                 |           |           |
| Residual Current Monitoring         | Integrated                 |           |           |
| Battery Reverse Polarity Protection | Integrated                 |           |           |
| Anti-islanding Protection           | Integrated                 |           |           |
| AC Overcurrent Protection           | Integrated                 |           |           |
| AC Short Circuit Protection         | Integrated                 |           |           |
| AC Overvoltage Protection           | Integrated                 |           |           |
| <b>General Data</b>                 |                            |           |           |
| Operating Temperature Range (°C)    | -25~+60                    |           |           |
| Relative Humidity                   | 0~95%                      |           |           |
| Max. Operating Altitude (m)         | 3000*8                     |           |           |
| Cooling Method                      | Natural Convection         |           |           |
| User Interface                      | LED, APP                   |           |           |
| Communication with BMS*3            | RS485, CAN                 |           |           |
| Communication with Meter            | RS485                      |           |           |
| Communication with Portal           | WiFi / Ethernet (Optional) |           |           |
| Weight (kg)                         | 17                         |           |           |
| Dimension (W×H×D mm)                | 354×433×147                |           |           |
| Noise Emission (dB)                 | <35                        |           |           |
| Topology                            | Non-isolated               |           |           |
| Self-consumption at Night (W)*4     | <10                        |           |           |

| Technical Data  | GW3600-EH   | GW5000-EH | GW6000-EH |
|---|---|-----------|-----------|
| Ingress Protection Rating   | IP65  |           |           |
| DC Connector  | MC4 (4~6 mm <sup>2</sup> )  |           |           |
| AC Connector  | Quick Plug  |           |           |
| Environmental Category  | 4K4H  |           |           |
| Pollution Degree  | III   |           |           |
| Overvoltage Category  | DC II / AC III  |           |           |
| Protective Class  | I   |           |           |
| Storage Temperature (°C)  | -40~+85   |           |           |
| The Decisive Voltage Class (DVC)  | Battery: C<br>PV: C<br>AC: C<br>Com: A  |           |           |
| Mounting Method   | Wall Mounted  |           |           |
| Active Anti-islanding Method  | AFDPF + AQDPF *7  |           |           |
| Type of Electrical Supply System  | Single phase TN/TT system   |           |           |
| Country of Manufacture  | China   |           |           |
| Certifications*4  |   |           |           |
| Grid Standards  | VDE-AR-N 4105, G98, G100, CEI 0-21, AS/NZS4777.2, NRS097-2-1                                    |           |           |
| Safety Regulation   | IEC/EN 62109-1&2  |           |           |
| EMC   | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4, EN 61000-4-16, EN 61000-4-18, EN 61000-4-29 |           |           |
| <p>*1: The grid feed in power for VDE-AR-N 4105 and NRS097-2-1 is limited 4600VA.<br/>           *2: CAN communication is configured by default. If 485 communication is used, please replace the corresponding communication line.<br/>           *3: No Back-up Output.<br/>           *4: Not all certifications &amp; standards listed, check the official website for details.<br/>           *5: For Brazil, the voltage is 220V.<br/>           *6: For Brazil, the current is 27.3A.<br/>           *7: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback.<br/>           *8: 2000m for Australia.</p> |   |           |           |

| Technical Data   | GW3600N-EH              | GW5000N-EH              | GW6000N-EH              |
|--|-------------------------|-------------------------|-------------------------|
| <b>Battery Input Data</b>  |                         |                         |                         |
| Battery Type   | Li-Ion                  | Li-Ion                  | Li-Ion                  |
| Nominal Battery Voltage (V)                                      | 350                     | 350                     | 350                     |
| Battery Voltage Range (V)  | 85~460                  | 85~460                  | 85~460                  |
| Start-up Voltage (V)   | 85                      | 85                      | 85                      |
| Number of Battery Input  | 1                       | 1                       | 1                       |
| Max. Continuous Charging Current (A)                             | 25                      | 25                      | 25                      |
| Max. Continuous Discharging Current (A)                          | 25                      | 25                      | 25                      |
| Max. Charge Power (W)  | 6,000                   | 6,000                   | 6,000                   |
| Max. Discharge Power (W)   | 3,600                   | 5,000                   | 6,000                   |
| <b>PV String Input Data</b>                                      |                         |                         |                         |
| Max. Input Power (W) <sup>*1</sup>                               | 5,400                   | 7,500                   | 9,000                   |
| Max. Input Voltage (V)   | 580                     | 580                     | 580                     |
| MPPT Operating Voltage Range (V)                                 | 100~550                 | 100~550                 | 100~550                 |
| MPPT Voltage Range at Nominal Power (V)                          | 150~550                 | 210~550                 | 250~550                 |
| Start-up Voltage (V)   | 85                      | 85                      | 85                      |
| Nominal Input Voltage (V)  | 380                     | 380                     | 380                     |
| Max. Input Current per MPPT (A)                                  | 16                      | 16                      | 16                      |
| Max. Short Circuit Current per MPPT (A)                          | 21.2                    | 21.2                    | 21.2                    |
| Max. Backfeed Current to The Array (A)                           | 0                       | 0                       | 0                       |
| Number of MPP Trackers   | 2                       | 2                       | 2                       |
| Number of Strings per MPPT                                       | 1                       | 1                       | 1                       |
| <b>AC Output Data (On-grid)</b>                                  |                         |                         |                         |
| Nominal Output Power (W)   | 3,600                   | 5,000                   | 6,000                   |
| Max. Output Power (W)  | 3600/3960 <sup>*2</sup> | 5000/5500 <sup>*2</sup> | 6000/6600 <sup>*2</sup> |
| Nominal Apparent Power Output to Utility Grid (VA) <sup>*3</sup> | 3,600                   | 5,000                   | 6,000                   |

| Technical Data   | GW3600N-EH                                      | GW5000N-EH                               | GW6000N-EH                                |
|--|---|--|---|
| Max. Apparent Power Output to Utility Grid (VA) <sup>3</sup> | 3600/3960 <sup>2</sup>                          | 5000/5500 <sup>2</sup>                   | 6000/6600 <sup>2</sup>                    |
| Nominal Apparent Power from Utility Grid (VA)                | 7200  | 10,000                                   | 12,000                                    |
| Max. Apparent Power from Utility Grid (VA)                   | 7200 (Charging 3.6kW, Backup Output 3.6kW)      | 10,000 (Charging 5kW, Backup Output 5kW) | 12,000 (Charging 6kW, Backup Output 6kW)  |
| Nominal Output Voltage (V)                                   | 230/220 <sup>7</sup>                            | 230/220 <sup>7</sup>                     | 230/220 <sup>7</sup>                      |
| Output Voltage Range (V)                                     | 0~300   | 0~300                                    | 0~300                                     |
| Nominal AC Grid Frequency (Hz)                               | 50/60   | 50/60                                    | 50/60                                     |
| AC Grid Frequency Range (Hz)                                 | 45~65   | 45~65                                    | 45~65                                     |
| Max. AC Current Output to Utility Grid (A)                   | 16/18 <sup>1</sup>                              | 21.7/24 <sup>1</sup>                     | 26.1/28.7 <sup>1</sup> /27.3 <sup>8</sup> |
| Max. AC Current From Utility Grid (A)                        | 32  | 43.4                                     | 52.2                                      |
| Nominal AC Current From Utility Grid (A)                     | 32  | 43.4                                     | 52.2                                      |
| Max. Output Fault Current (Peak and Duration) (A)            | 65A@5μs   | 65A@5μs                                  | 65A@5μs                                   |
| Inrush Current (Peak and Duration) (A)                       | 65A@5μs   | 65A@5μs                                  | 65A@5μs                                   |
| Nominal Output Current (A)                                   | 15.6  | 21.7                                     | 26.1                                      |
| Power Factor   | ~1 (Adjustable from 0.8 leading to 0.8 lagging) |  |   |
| Max. Total Harmonic Distortion                               | <3%   | <3%                                      | <3%                                       |
| Maximum Output Overcurrent Protection (A)                    | 17.2  | 23.9                                     | 28.7                                      |
| Type of Voltage (a.c. or d.c.)                               | a.c.  | a.c.                                     | a.c.                                      |
| <b>AC Output Data (Back-up)</b>                              |   |  |   |
| Back-up Nominal Apparent Power (VA)                          | 3600  | 5000                                     | 6,000                                     |
| Max. Output Apparent Power without Grid(VA)                  | 3600<br>(4320@60sec)                            | 5000<br>(6000@60sec)                     | 6,000<br>(7200@60sec)                     |

| Technical Data                                    | GW3600N-EH    | GW5000N-EH    | GW6000N-EH    |
|---|---------------|---------------|---------------|
| Max. Output Apparent Power with Grid(VA)          | 3600          | 5000          | 6,000         |
| Nominal Output Current (A)                        | 15.7          | 21.7          | 26.1          |
| Max. Output Current (A)                           | 15.7          | 21.7          | 26.1          |
| Max. Output Fault Current (Peak and Duration) (A) | 65A@5μs       | 65A@5μs       | 65A@5μs       |
| Inrush Current (Peak and Duration) (A)            | 65A@5μs       | 65A@5μs       | 65A@5μs       |
| Maximum Output Overcurrent Protection (A)         | 18.8          | 26.1          | 31.3          |
| Nominal Output Voltage (V)                        | 230 (±2%)     | 230 (±2%)     | 230 (±2%)     |
| Nominal Output Frequency (Hz)                     | 50/60 (±0.2%) | 50/60 (±0.2%) | 50/60 (±0.2%) |
| Output THDv (@Linear Load)                        | <3%           | <3%           | <3%           |
| <b>Efficiency</b>                                 |               |               |               |
| Max. Efficiency                                   | 97.6%         | 97.6%         | 97.6%         |
| European Efficiency                               | 97.0%         | 97.0%         | 97.0%         |
| Max. Battery to AC Efficiency                     | 96.6%         | 96.6%         | 96.6%         |
| MPPT Efficiency                                   | 99.9%         | 99.9%         | 99.9%         |
| <b>Protection</b>                                 |               |               |               |
| PV String Current Monitoring                      | Integrated    | Integrated    | Integrated    |
| PV Insulation Resistance Detection                | Integrated    | Integrated    | Integrated    |
| Residual Current Monitoring                       | Integrated    | Integrated    | Integrated    |
| PV Reverse Polarity Protection                    | Integrated    | Integrated    | Integrated    |
| Battery Reverse Polarity Protection               | Integrated    | Integrated    | Integrated    |
| Anti-islanding Protection                         | Integrated    | Integrated    | Integrated    |
| AC Overcurrent Protection                         | Integrated    | Integrated    | Integrated    |
| AC Short Circuit Protection                       | Integrated    | Integrated    | Integrated    |
| AC Overvoltage Protection                         | Integrated    | Integrated    | Integrated    |
| DC Switch   | Integrated    | Integrated    | Integrated    |
| DC Surge Protection                               | Type II       | Type II       | Type II       |
| AC Surge protection                               | Type III      | Type III      | Type III      |

| Technical Data                             | GW3600N-EH                             | GW5000N-EH                             | GW6000N-EH                             |
|--|--|--|--|
| Remote Shutdown                            | Integrated                             | Integrated                             | Integrated                             |
| <b>General Data</b>                        |  |  |  |
| Operating Temperature Range (°C)           | -25~+60                                | -25~+60                                | -25~+60                                |
| Relative Humidity                          | 0~95%                                  | 0~95%                                  | 0~95%                                  |
| Max. Operating Altitude (m)                | 3000*10                                | 3000*10                                | 3000*10                                |
| Cooling Method                             | Natural Convection                     | Natural Convection                     | Natural Convection                     |
| User Interface                             | LED, APP                               | LED, APP                               | LED, APP                               |
| Communication with BMS <sup>4</sup>        | RS485, CAN                             | RS485, CAN                             | RS485, CAN                             |
| Communication with Meter                   | RS485                                  | RS485                                  | RS485                                  |
| Communication with Portal                  | WiFi / Ethernet (Optional)             | WiFi / Ethernet (Optional)             | WiFi / Ethernet (Optional)             |
| Weight (kg)                                | 17                                     | 17                                     | 17                                     |
| Dimension (W×H×D mm)                       | 354×433×147                            | 354×433×147                            | 354×433×147                            |
| Noise Emission (dB)                        | <35                                    | <35                                    | <35                                    |
| Topology                                   | Non-isolated                           | Non-isolated                           | Non-isolated                           |
| Self-consumption at Night (W) <sup>5</sup> | <10                                    | <10                                    | <10                                    |
| Ingress Protection Rating                  | IP65                                   | IP65                                   | IP65                                   |
| DC Connector                               | MC4 (4~6 mm <sup>2</sup> )             | MC4 (4~6 mm <sup>2</sup> )             | MC4 (4~6 mm <sup>2</sup> )             |
| AC Connector                               | Quick Plug                             | Quick Plug                             | Quick Plug                             |
| Environmental Category                     | 4K4H                                   | 4K4H                                   | 4K4H                                   |
| Pollution Degree                           | III                                    | III                                    | III                                    |
| Overvoltage Category                       | DC II / AC III                         | DC II / AC III                         | DC II / AC III                         |
| Protective Class                           | I                                      | I                                      | I                                      |
| Storage Temperature (°C)                   | -40~+85                                | -40~+85                                | -40~+85                                |
| The Decisive Voltage Class (DVC)           | Battery: C<br>PV: C<br>AC: C<br>Com: A | Battery: C<br>PV: C<br>AC: C<br>Com: A | Battery: C<br>PV: C<br>AC: C<br>Com: A |
| Mounting Method                            | Wall Mounted                           | Wall Mounted                           | Wall Mounted                           |
| Active Anti-islanding Method               | AFDPF+ AQDPF <sup>9</sup>              | AFDPF+ AQDPF <sup>9</sup>              | AFDPF+ AQDPF <sup>9</sup>              |



| Technical Data   | GW3600N-EH  | GW5000N-EH                | GW6000N-EH                |
|--|---|---------------------------|---------------------------|
| Type of Electrical Supply System   | Single phase TN/TT system   | Single phase TN/TT system | Single phase TN/TT system |
| Country of Manufacture   | China   | China                     | China                     |
| <b>Certifications*<sup>6</sup></b>   |   |                           |                           |
| Grid Standards   | VDE-AR-N 4105, G98, G100, CEI 0-21, AS/NZS4777.2, NRS097-2-1                                    |                           |                           |
| Safety Regulation  | IEC/EN 62109-1&2  |                           |                           |
| EMC  | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4, EN 61000-4-16, EN 61000-4-18, EN 61000-4-29 |                           |                           |
| <p>*1: In Australia, for most of the PV module, the max. input power can achieve 2*P<sub>n</sub>, Such as the max. input power of GW3600N-EH can achieve 7200W</p> <p>*2: For CEI 0-21.</p> <p>*3: The grid feed in power for VDE-AR-N 4105 and NRS097-2-1 is limited 4600VA.</p> <p>*4: CAN communication is configured by default. If 485 communication is used, please replace the corresponding communication line.</p> <p>*5: No Back-up Output.</p> <p>*6: Not all certifications &amp; standards listed, check the official website for details.</p> <p>*7: For Brazil, the voltage is 220V.</p> <p>*8: For Brazil, the current is 27.3A.</p> <p>*9: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback.</p> <p>*10: 2000m for Australia.</p> |   |                           |                           |

| Technical Data                                     | GW5000N-EH-BE | GW5000-EH-BE |
|--|---------------|--------------|
| <b>Battery Input Data</b>                          |               |              |
| Battery Type                                       | Li-Ion        | Li-Ion       |
| Nominal Battery Voltage (V)                        | 350           | 350          |
| Battery Voltage Range (V)                          | 85~460        | 85~460       |
| Start-up Voltage (V)                               | 85            | 85           |
| Number of Battery Input                            | 1             | 1            |
| Max. Continuous Charging Current (A)               | 25            | 25           |
| Max. Continuous Discharging Current (A)            | 25            | 25           |
| Max. Charge Power (W)                              | 6,000         | 5,000        |
| Max. Discharge Power (W)                           | 5,000         | 5,000        |
| <b>PV String Input Data</b>                        |               |              |
| Max. Input Power (W)                               | 7,500         | 6,650        |
| Max. Input Voltage (V)                             | 580           | 580          |
| MPPT Operating Voltage Range (V)                   | 100~550       | 100~550      |
| MPPT Voltage Range at Nominal Power (V)            | 210~550       | 210~550      |
| Start-up Voltage (V)                               | 85            | 90           |
| Nominal Input Voltage (V)                          | 380           | 380          |
| Max. Input Current per MPPT (A)                    | 16            | 12.5         |
| Max. Short Circuit Current per MPPT (A)            | 21.2          | 15.2         |
| Max. Backfeed Current to The Array (A)             | 0             | 0            |
| Number of MPP Trackers                             | 2             | 2            |
| Number of Strings per MPPT                         | 1             | 1            |
| <b>AC Output Data (On-grid)</b>                    |               |              |
| Nominal Output Power (W)                           | 5,000         | 5,000        |
| Max. Output Power (W)                              | 5000          | 5000         |
| Nominal Apparent Power Output to Utility Grid (VA) | 5,000         | 5,000        |

| Technical Data                                    | GW5000N-EH-BE                                   | GW5000-EH-BE                           |
|---|---|--|
| Max. Apparent Power Output to Utility Grid (VA)   | 5000  | 5000                                   |
| Nominal Apparent Power from Utility Grid (VA)     | 10,000  | 10,000                                 |
| Max. Apparent Power from Utility Grid (VA)        | 10,000 (Charging 5kW, Backup Output 5kW)        | 10000(Charging 5kw, Backup Output 5kw) |
| Nominal Output Voltage (V)                        | 230   | 230                                    |
| Output Voltage Range (V)                          | 0~300   | 0~300                                  |
| Nominal AC Grid Frequency (Hz)                    | 50/60   | 50/60                                  |
| AC Grid Frequency Range (Hz)                      | 45~65   | 45~65                                  |
| Max. AC Current Output to Utility Grid (A)        | 21.7  | 21.7                                   |
| Max. AC Current From Utility Grid (A)             | 43.4  | 43.4                                   |
| Nominal AC Current From Utility Grid (A)          | 43.4  | -                                      |
| Max. Output Fault Current (Peak and Duration) (A) | 65A@5 $\mu$ s                                   | 65@5 $\mu$ s                           |
| Inrush Current (Peak and Duration) (A)            | 65A@5 $\mu$ s                                   | 65@5 $\mu$ s                           |
| Nominal Output Current (A)                        | 21.7  | 21.7                                   |
| Power Factor                                      | ~1 (Adjustable from 0.8 leading to 0.8 lagging) |  |
| Max. Total Harmonic Distortion                    | <3%   | <3%                                    |
| Maximum Output Overcurrent Protection (A)         | 23.9  | 54                                     |
| Type of Voltage (a.c. or d.c.)                    | a.c.  | -                                      |
| <b>AC Output Data (Back-up)</b>                   |   |  |
| Back-up Nominal Apparent Power (VA)               | 5000  | 5,000                                  |
| Max. Output Apparent Power without Grid(VA)       | 5000  | 5000                                   |
| Max. Output Apparent Power with Grid(VA)          | 5000  | 5,000                                  |
| Nominal Output Current (A)                        | 21.7  | 21.7                                   |
| Max. Output Current (A)                           | 21.7  | 21.7                                   |

| Technical Data                                    | GW5000N-EH-BE       | GW5000-EH-BE        |
|---|---------------------|---------------------|
| Max. Output Fault Current (Peak and Duration) (A) | 65A@5 $\mu$ s       | 26@60s              |
| Inrush Current (Peak and Duration) (A)            | 65A@5 $\mu$ s       | 65@5 $\mu$ s        |
| Maximum Output Overcurrent Protection (A)         | 26.1                | 21.7                |
| Nominal Output Voltage (V)                        | 230 ( $\pm$ 2%)     | 230 ( $\pm$ 2%)     |
| Nominal Output Frequency (Hz)                     | 50/60 ( $\pm$ 0.2%) | 50/60 ( $\pm$ 0.2%) |
| Output THDv (@Linear Load)                        | <3%                 | <3%                 |
| <b>Efficiency</b>                                 |                     |                     |
| Max. Efficiency                                   | 97.6%               | 97.6%               |
| European Efficiency                               | 97.0%               | 97.0%               |
| Max. Battery to AC Efficiency                     | 96.6%               | 96.6%               |
| MPPT Efficiency                                   | 99.9%               | 99.9%               |
| <b>Protection</b>                                 |                     |                     |
| PV String Current Monitoring                      | Integrated          | -                   |
| PV Insulation Resistance Detection                | Integrated          | Integrated          |
| Residual Current Monitoring                       | Integrated          | Integrated          |
| PV Reverse Polarity Protection                    | Integrated          | -                   |
| Battery Reverse Polarity Protection               | Integrated          | Integrated          |
| Anti-islanding Protection                         | Integrated          | Integrated          |
| AC Overcurrent Protection                         | Integrated          | Integrated          |
| AC Short Circuit Protection                       | Integrated          | Integrated          |
| AC Overvoltage Protection                         | Integrated          | Integrated          |
| DC Switch   | Integrated          | -                   |
| DC Surge Protection                               | Type II             | -                   |
| AC Surge protection                               | Type III            | -                   |
| Remote Shutdown                                   | Integrated          | -                   |
| <b>General Data</b>                               |                     |                     |
| Operating Temperature Range ( $^{\circ}$ C)       | -25~+60             | -25~+60             |
| Relative Humidity                                 | 0~95%               | 0~95%               |
| Max. Operating Altitude (m)                       | 3000                | 3000                |

| Technical Data                       | GW5000N-EH-BE  | GW5000-EH-BE   |
|--------------------------------------|--|--|
| Cooling Method                       | Natural Convection   | Natural Convection   |
| User Interface                       | LED, APP   | LED, APP   |
| Communication with BMS <sup>*1</sup> | RS485, CAN   | RS485, CAN   |
| Communication with Meter             | RS485  | RS485  |
| Communication with Portal            | WiFi / Ethernet (Optional)                                   | WiFi / Ethernet (Optional)                                   |
| Weight (kg)                          | 17   | 17   |
| Dimension (W×H×D mm)                 | 354×433×147  | 354×433×147  |
| Noise Emission (dB)                  | <35  | <35  |
| Topology                             | Non-isolated   | Non-isolated   |
| Self-consumption at Night (W)        | <10 <sup>*2</sup>  | <10  |
| Ingress Protection Rating            | IP65   | IP65   |
| DC Connector                         | MC4 (4~6 mm <sup>2</sup> )                                   | MC4 (4~6 mm <sup>2</sup> )                                   |
| AC Connector                         | Quick Plug   | Quick Plug   |
| Environmental Category               | 4K4H   | 4K4H   |
| Pollution Degree                     | III  | III  |
| Overvoltage Category                 | DC II / AC III   | DC II / AC III   |
| Protective Class                     | I  | I  |
| Storage Temperature (°C)             | -40~+85  | -40~+85  |
| The Decisive Voltage Class (DVC)     | Battery: C<br>PV: C<br>AC: C<br>Com: A                       | Battery: C<br>PV: C<br>AC: C<br>Com: A                       |
| Mounting Method                      | Wall Mounted   | Wall Mounted   |
| Active Anti-islanding Method         | AFDPF+ AQDPF <sup>*4</sup>                                   | AFDPF+ AQDPF   |
| Type of Electrical Supply System     | Single phase TN/TT system                                    | Single phase TN/TT system                                    |
| Country of Manufacture               | China  | China  |
| <b>Certification<sup>*3</sup></b>    |  |  |
| Grid Standards                       | VDE-AR-N 4105, G98, G100, CEI 0-21, AS/NZS4777.2, NRS097-2-1 | VDE-AR-N 4105, G98, G100, CEI 0-21, AS/NZS4777.2, NRS097-2-1 |
| Safety Regulation                    | IEC/EN 62109-1&2   | IEC/EN 62109-1&2   |

| Technical Data   | GW5000N-EH-BE   | GW5000-EH-BE  |
|--|---|---|
| EMC  | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4, EN 61000-4-16, EN 61000-4-18, EN 61000-4-29 | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4, EN 61000-4-16, EN 61000-4-18, EN 61000-4-29 |
| <p>*1: CAN communication is configured by default. If 485 communication is used, please replace the corresponding communication line.</p> <p>*2: No Back-up Output.</p> <p>*3: Not all certifications &amp; standards listed, check the official website for details.</p> <p>*4: AFDPF: Active Frequency Drift with Positive Feedback, AQDPF: Active Q Drift with Positive Feedback.</p> |   |   |




Official Website

GoodWe Technologies Co.,Ltd.

---

 No. 90 Zijin Rd., New District, Suzhou, 215011, China

 [www.goodwe.com](http://www.goodwe.com)

 [service@goodwe.com](mailto:service@goodwe.com)



Contact Information