

ABD Series Automatic Backup Device

(ABD200-40-US10 | ABD200-63-US10 | ABD100-40-US10 | ABD100-63-US10)

MPD Series Multi-inverter Parallel Device

(MPD200-40-US10 | MPD200-63-US10)

Quick Installation Guide

Copyright ©GOODWE VIET NAM TECHNOLOGY CO.,LTD.,2025. All rights reserved.

- The information in this quick installation guide is subject to change due to product updates or other reasons. This guide cannot replace the product labels or the safety precautions in the user manual unless otherwise specified. All descriptions here are for guidance only.
- All operations should be performed by trained and knowledgeable technicians who are familiar with local standards and safety regulations.
- Strictly follow the installation, operation, and configuration instructions in this guide and user manual. The manufacturer shall not be liable for equipment damage or personal injury if you do not follow the instructions.



Official Website



340-01321-00


GOODWE VIET NAM TECHNOLOGY CO.,LTD

E-mail: Service@goodwe.com

Website: www.goodwe.com


Address: Factory A1, A2, Lot CN1N, Maritime Industrial and Service Park (Deep C2B), Dinh Vu - Cat Hai Economic Zone, Dong Hai 2 Ward, Hai An District, Hai Phong City, Vietnam

1 Installation




ABD10INT0001

Procedure




ABD10INT0002



ABD10INT0003


2 Electrical Connection

Preparations before Electrical Connection



ABD10INT0004


AC (GRID)






ABD10ELC0001

Procedure


AC (LOAD)




AC (INVERTER)



COM (CT)



COM (Inverter)



3 Commissioning and Monitoring

